

OA Centers for Orthopedics
 33 Sewall Street
 Portland, ME

SEQUENCE OF OPERATION MATRIX

	<div style="display: flex; justify-content: space-between;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Alarm Signal to Central Station via Digital Communicator (DACT)</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Annunciate at Fire Alarm Control Panel</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Activate Horn/Strobe Circuit</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Activate Exterior Strobe Beacon</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Supervisory Signal to Central Station via Digital Dialer (DACT)</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Trouble Signal to Central Station via Digital Communicator (DACT)</div> </div>						
System Inputs	A	B	C	D	E	F	System Inputs
System Waterflow							System Waterflow
System Tamper Switch							System Tamper Switch
Manual Pull Stations		x	x	x			Manual Pull Stations
Area Smoke Detector							Area Smoke Detector
Area Heat Detector							Area Heat Detector
Pre-Action Alarm		x	x	x			Pre-Action Alarm
Pre-Action Fault					x		Pre-Action Fault
Fire Alarm - AC Failure		x		x		x	Fire Alarm - AC Failure
Fire Alarm - Low Battery		x				x	Fire Alarm - Low Battery
Signal Line Open Circuit		x				x	Signal Line Open Circuit
Signal Line Ground Fault		x				x	Signal Line Ground Fault
Horn/Strobe Circuit Open		x				x	Horn/Strobe Circuit Open
Horn/Strobe Circuit Ground		x				x	Horn/Strobe Circuit Ground
System Ground Fault		x				x	System Ground Fault
	A	B	C	D	E	F	