

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY	
	A	B	C						A	B	C		
	*	*	*	1	20			2	1.4	*		LTG SHELL SPACE	
PANELBOARD PP3C, PP3D	*	*	*	3	125			4	1.1	*		LTG FOURTH FLOOR	
SPACE	*	*	*	5				6		*		SPARE	
SPACE	*	*	*	7				8		*		SPARE	
SPACE	*	*	*	9				10		*		SPARE	
SPACE	*	*	*	11				12		*		SPARE	
SPACE	*	*	*	13				14		*		SPARE	
SPACE	*	*	*	15				16		*		SPARE	
SPACE	*	*	*	17				18		*		SPARE	
SPACE	*	*	*	19				20		*		SPARE	
SPACE	*	*	*	21				22		*		SPACE	
SPACE	*	*	*	23				24		*		SPACE	
SPACE	*	*	*	25				26		*		SPACE	
SPACE	*	*	*	27				28		*		SPACE	
SPACE	*	*	*	29				30		*		SPACE	
SPACE	*	*	*	31				32		*		SPACE	
SPACE	*	*	*	33				34		*		SPACE	
SPACE	*	*	*	35				36		*		SPACE	
SPACE	*	*	*	37				38		*		SPACE	
SPACE	*	*	*	39				40		*		SPACE	
SPACE	*	*	*	41				42		*		SPACE	
SUB-TOTAL				NEUTRAL BUS				SUB-TOTAL					
VOLTAGE: 480Y/277V				3 PHASE 4 WIRE				400 AMP BUS				TOTAL KVA A	
MAIN LUGS ONLY:				300 AMP LUGS				TOTAL KVA B				PANEL NO. LP3B	
MOUNTING: SURFACE				TOTAL KVA C				LOCATION				ELECTRICAL RM	
SC RATING: 64,000 AIC				TOTAL KVA				NOTES:					

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY	
	A	B	C						A	B	C		
SPARE	*	*	*	1	20			2		*		SPARE	
SPARE	*	*	*	3	20			4		*		SPARE	
SPARE	*	*	*	5	20			6		*		SPARE	
SPARE	*	*	*	7	20			8		*		SPARE	
SPARE	*	*	*	9	20			10		*		SPARE	
SPARE	*	*	*	11	20			12		*		SPARE	
SPARE	*	*	*	13	20			14		*		SPARE	
SPARE	*	*	*	15	20			16		*		SPARE	
SPARE	*	*	*	17	20			18		*		SPARE	
SPARE	*	*	*	19	20			20		*		SPARE	
SPARE	*	*	*	21	20			22		*		SPARE	
SPARE	*	*	*	23	20			24		*		SPARE	
SPARE	*	*	*	25	20			26		*		SPARE	
SPARE	*	*	*	27	20			28		*		SPARE	
SPARE	*	*	*	29	20			30		*		SPARE	
SPARE	*	*	*	31	20			32		*		SPACE	
SPARE	*	*	*	33	20			34		*		SPACE	
SPARE	*	*	*	35	20			36		*		SPACE	
SPARE	*	*	*	37	20			38		*		SPACE	
SPARE	*	*	*	39	20			40		*		SPACE	
SPARE	*	*	*	41	20			42		*		SPACE	
SUB-TOTAL				NEUTRAL BUS				SUB-TOTAL					
VOLTAGE: 208Y/120V				3 PHASE 4 WIRE				225 AMP BUS				TOTAL KVA A	
MAIN LUGS ONLY:				225 AMP LUGS				TOTAL KVA B				PANEL NO. PP1B	
MOUNTING: SURFACE				TOTAL KVA C				LOCATION				ELECTRICAL RM	
SC RATING: 10,000 AIC				TOTAL KVA				NOTES:					

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY	
	A	B	C						A	B	C		
	*	*	*	1	20			2	1.4	*		LTG SHELL SPACE	
PANELBOARD PP4A, PP4B	*	*	*	3	125			4		*		SPARE	
SPACE	*	*	*	5				6		*		SPARE	
SPACE	*	*	*	7				8		*		SPARE	
SPACE	*	*	*	9				10		*		SPARE	
SPACE	*	*	*	11				12		*		SPARE	
SPACE	*	*	*	13				14		*		SPARE	
SPACE	*	*	*	15				16		*		SPARE	
SPACE	*	*	*	17				18		*		SPARE	
SPACE	*	*	*	19				20		*		SPACE	
SPACE	*	*	*	21				22		*		SPACE	
SPACE	*	*	*	23				24		*		SPACE	
SPACE	*	*	*	25				26		*		SPACE	
SPACE	*	*	*	27				28		*		SPACE	
SPACE	*	*	*	29				30		*		SPACE	
SPACE	*	*	*	31				32		*		SPACE	
SPACE	*	*	*	33				34		*		SPACE	
SPACE	*	*	*	35				36		*		SPACE	
SPACE	*	*	*	37				38		*		SPACE	
SPACE	*	*	*	39				40		*		SPACE	
SPACE	*	*	*	41				42		*		SPACE	
SUB-TOTAL				NEUTRAL BUS				SUB-TOTAL					
VOLTAGE: 480Y/277V				3 PHASE 4 WIRE				400 AMP BUS				TOTAL KVA A	
MAIN LUGS ONLY:				300 AMP LUGS				TOTAL KVA B				PANEL NO. LP4A	
MOUNTING: SURFACE				TOTAL KVA C				LOCATION				ELECTRICAL RM	
SC RATING: 64,000 AIC				TOTAL KVA				NOTES:					

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY	
	A	B	C						A	B	C		
SPARE	*	*	*	1	20			2	0.9	*		RECEPTS ELECTRICAL/STAIR/EXT.	
SPARE	*	*	*	3	20			4	1.1	*		RECEPTS SHELL SPACE	
SPARE	*	*	*	5	20			6		*		RECEPTS SHELL SPACE	
SPARE	*	*	*	7	20			8		*		RECEPTS UTILITY RM	
SPARE	*	*	*	9	20			10		*		RECEPTS ELEC RM	
SPARE	*	*	*	11	20			12		*		SPARE	
SPARE	*	*	*	13	20			14		*		SPARE	
SPARE	*	*	*	15	20			16		*		SPARE	
SPARE	*	*	*	17	20			18		*		SPARE	
SPARE	*	*	*	19	20			20		*		SPARE	
SPARE	*	*	*	21	20			22		*		SPARE	
SPARE	*	*	*	23	20			24		*		SPARE	
SPARE	*	*	*	25	20			26		*		SPARE	
SPARE	*	*	*	27	20			28		*		SPARE	
SPARE	*	*	*	29	20			30		*		SPARE	
SPARE	*	*	*	31	20			32		*		SPARE	
SPARE	*	*	*	33	20			34		*		SPARE	
SPARE	*	*	*	35	20			36		*		SPARE	
SPARE	*	*	*	37	20			38		*		SPARE	
SPARE	*	*	*	39	20			40		*		SPARE	
SPARE	*	*	*	41	20			42		*		SPARE	
SUB-TOTAL				NEUTRAL BUS				SUB-TOTAL					
VOLTAGE: 208Y/120V				3 PHASE 4 WIRE				225 AMP BUS				TOTAL KVA A	
MAIN BREAKER				225 AMP TRIP				TOTAL KVA B				PANEL NO. PP1C	
MOUNTING: SURFACE				TOTAL KVA C				LOCATION				ELECTRICAL RM	
SC RATING: 10,000 AIC				TOTAL KVA				NOTES:				1. PANELBOARD TO BE PROVIDED WITH FEED THROUGH LUGS.	

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY	
	A	B	C						A	B	C		
SPARE	*	*	*	1	20			2	0.9	*		RECEPTS ELECTRICAL/STAIR/EXT.	
SPARE	*	*	*	3	20			4	1.1	*		RECEPTS SHELL SPACE	
SPARE	*	*	*	5	20			6		*		RECEPTS SHELL SPACE	
SPARE	*	*	*	7	20			8		*		SPARE	
SPARE	*	*	*	9	20			10		*		SPARE	
SPARE	*	*	*	11	20			12		*		SPARE	
SPARE	*	*	*	13	20			14		*		SPARE	
SPARE	*	*	*	15	20			16		*		SPARE	
SPARE	*	*	*	17	20			18		*		SPARE	
SPARE	*	*	*	19	20			20		*		SPARE	
SPARE	*	*	*	21	20			22		*		SPARE	
SPARE	*	*	*	23	20			24		*		SPARE	
SPARE	*	*	*	25	20			26		*		SPARE	
SPARE	*	*	*	27	20			28		*		SPARE	
SPARE	*	*	*	29	20			30		*		SPACE	
SPARE	*	*	*	31	20			32		*		SPACE	
SPARE	*	*	*	33	20			34		*		SPACE	
SPARE	*	*	*	35	20			36		*		SPACE	
SPARE	*	*	*	37	20			38		*		SPACE	
SPARE	*	*	*	39	20			40		*		SPACE	
SPARE	*	*	*	41	20			42		*		SPACE	
SUB-TOTAL				NEUTRAL BUS				SUB-TOTAL					
VOLTAGE: 208Y/120V				3 PHASE 4 WIRE				225 AMP BUS				TOTAL KVA A	
MAIN BREAKER				225 AMP TRIP				TOTAL KVA B				PANEL NO. PP1A	
MOUNTING: SURFACE				TOTAL KVA C				LOCATION				ELECTRICAL RM	
SC RATING: 10,000 AIC				TOTAL KVA				NOTES:				1. PANELBOARD TO BE PROVIDED WITH FEED THROUGH LUGS.	

DIRECTORY	KVA LOAD			CKT NO.	BKR AMPS	A B C	BKR AMPS	CKT NO.	KVA LOAD			DIRECTORY
	A	B	C						A	B	C	
SPARE	*	*	*	1	20			2		*		SPARE
SPARE	*	*	*	3	20			4		*		SPARE
SPARE	*	*	*	5	20			6		*		SPARE
SPARE	*	*	*	7	20			8		*		SPARE
SPARE	*	*	*	9	20			10		*		SPARE
SPARE	*	*	*	11	20			12</				