




ALL WINDOWS TO BE ANDERSEN E-SERIES INSULATED LOW-E, ARGON FILLED WITH U FACTOR OF 0.30



**6 | BRICK TO CONCRETE DETAIL**  
 1 1/2" = 1'-0"



**3 | WINDOW HEAD AND CORNICE DETAIL**  
 3" = 1'-0"




**ORDER OF INSTALLATION OF WATER PROOFING AT WINDOWS. WATER PROOFING AT STOREFRONT AND DOORS USE STEPS 1-3**


NOTES:  
 1. INSTALL AIR INFILTRATION BARRIER IN ORDER AS SHOWN BY NUMBERS.  
 2. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN.  
 3. INSTALL FLASHING AND AIR INFILTRATION BARRIER TO FORM WATER SHEDDING LAPS  
 4. COORDINATE WITH FLASHING REQUIREMENTS OF WINDOW MANUFACTURER  
 5. FOLLOW MANUFACTURERS RECOMMENDATIONS FOR INSTALLATION.

NOTE: MOCK-UP FIRST WINDOW TO BE APPROVED BY MSHA, AND ARCHITECT PRIOR TO ANY INSTALLATION

**7 | ORDER OF INSTALLATION OF WATERPROOFING AT WINDOWS**  
 3/8" = 1'-0"



**2 | WINDOW JAMB DETAIL**  
 3" = 1'-0"



**1 | WINDOW SILL DETAIL**  
 3" = 1'-0"