

SEQUENCE OF OPERATION MATRIX

	<div style="display: flex; justify-content: space-between;"> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Alarm Signal to Central Station via Radio Master Box</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Alarm Signal Sent To Central Station via Digital Communicator (DACT)</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Annunciate at Fire Alarm Control Panel and Annunciator</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Activate Evacuation Sequence</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Recall Elevator To Appropriate Floor (Primary Or Alternate)</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Active Relays For Elevator Shunt</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Record Event In Memory</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Supervisory Signal to Central Station via Digital Communicator (DACT)</div> <div style="writing-mode: vertical-rl; transform: rotate(180deg);">Trouble Signal to Central Station via Digital Communicator (DACT)</div> </div>									
System Inputs	A	B	C	D	E	F	G	H	I	System Inputs
System Waterflow	x	x	x	x			x			System Waterflow
System Tamper Switch			x				x	x		System Tamper Switch
Manual Pull Station	x	x	x	x			x			Manual Pull Station
Area Smoke Detector	x	x	x	x			x			Area Smoke Detector
Elevator Smoke Detector	x	x	x	x	x		x			Elevator Smoke Detector
Elevator Heat Detector	x	x	x	x		x	x			Elevator Heat Detector
Carbon Monoxide Detector	x	x	x	x			x			Carbon Monoxide Detector
Fire Alarm - AC Failure			x				x		x	Fire Alarm - AC Failure
Fire Alarm - Low Battery			x				x		x	Fire Alarm - Low Battery
Signal Line Open Circuit			x				x		x	Signal Line Open Circuit
Signal Line Ground Fault			x				x		x	Signal Line Ground Fault
Horn/Strobe Circuit Open			x				x		x	Horn/Strobe Circuit Open
Horn/Strobe Circuit Ground			x				x		x	Horn/Strobe Circuit Ground
System Ground Fault			x				x		x	System Ground Fault
	A	B	C	D	E	F	G	H	I	