

iO500 Intelligent Life Safety System





Overview

The EST iO500 intelligent life safety system offers the power of high-end intelligent processing in a configuration that delivers an uncomplicated solution for small to mid-sized applications. With intelligent detection, electronic addressing, automatic device mapping, optional Ethernet® connectivity, and a full line of easily-configured option cards and modules, this flexible system offers offers versatility that benefits building owners and contractors alike.

The iO500 provides one Class A or Class B analog device loop that supports up to 250 device addresses. A second 250-point loop may be added to the iO500 to expand total system capacity to up to 500 device addresses. The panel includes four NACs that may be wired for either Class A or Class B operation.

The iO500 supports a wide range of accessories and related equipment, including:

- Signature Series intelligent modules, detectors, and bases
- R-Series remote annunciators
- option cards that expand system capacity and extend system capabilities
- Listed for releasing applications using SIGA-REL
- Fully integrated CO detection using Signature Series 2 detectors with or w/o audible signaling

Features

- Comes standard with one loop (expandable to two) that supports up to 250 (expandable to 500) intelligent devices: each iO500 loop supports up to 125 detectors and up to 125 modules.
- Supports Signature Series intelligent modules and detectors
- Combines the Signature intelligent releasing module with Signature multisensor detectors for reliable suppression
- Four Class B NACs or two Class A NACs.
- Form C contacts for alarm and trouble, Form A for supervisory
- Electronic addressing with automatic device mapping
- Optional Ethernet port for diagnostics, programming and a variety of system reports
- Two programmable switches with LEDs and custom labeling
- Supports Genesis horn silence over two wires and UL 1971-compliant strobe synchronization
- Supports up to eight serial annunciators, (LCD, LED-only, and graphic interface).
- 1,000 event panel history log
- Can use existing wiring for most retrofit applications
- Upload/download remotely or locally
- Two-level maintenance alert reporting
- Pre-alarm and alarm verification by point
- Adjustable detector sensitivity
- 4 x 20 character backlit LCD display
- Optional earthquake hardening: OSHPD seismic pre-approval for component Importance Factor 1.5

Application

The iO500 life safety system is a powerful intelligent solution for small to mid-sized buildings. Advanced analog technology delivers the benefits of flexible system installation, while a clean and easy-to-operatate user interface makes panel operation and system maintenance quick and intuitive.

The smart choice

Signature Series electronic addressing eliminates the tedium of setting dipswitches, and automatic device mapping ensures that each device resides on the system at its correct location. Meanwhile, innovative programming allows the designer to customize the system to precisely suit the needs of the building owner.

Flexibility built right in

Two fully-programmable front panel switch/LED combinations provide an added measure of flexibility. Their slide-in labels take the mystery out of custom applications, and present a clean finished appearance.

Perfect for retrofits

The iO500 is particularly well-suited to retrofit applications. All connections are made over standard wiring – no shielded cable required. This means that in most situations existing wiring can be used to upgrade a legacy control panel to iO500 technology without the expense or disruption of rewiring the entire building.

Signals with a difference

iO500 NACs are configurable to fully support the advanced signaling technology of Edwards Genesis and Enhanced Integrity notification appliances. These devices offer precision synchronization of strobes to UL 1971 standards. For Genesis devices, enabling this feature allows connected horns to be silenced while strobes on the same two-wire circuit continue to flash until the panel is reset.

Clear-cut remote annunciation

Remote annunciation is a strong suit of the iO500. Up to eight annunciators can be installed on a single system. Compatible annunciators include a range of LED and LCD models that provide zone or point annunciation, as well as common control capabilities.


The iO500 also supports graphic annunciation with optional graphic annunciator interface modules. Each interface provides common control, indicators, and LED drivers. Consult the Ordering Information section for details.

A complete line of accessories

The iO500 life safety system is supported by a complete line of intelligent detectors, modules and related equipment. Consult the Ordering Information section for details.

Operation

The front panel provides an easy-to-use operator's interface, as well as all the necessary controls for front panel programming. A large back-lit 80-character LCD displays system status, event details, and programming prompts. Large tactile control buttons are easy to see in low light condi-



tions, and bright multi-color LEDs offer at-a-glance status indication.

Control buttons

| Button | Description | |
|------------------------|--|--|
| Reset | Initiates a system reset. | |
| ACK/Panel Silence | Silences the panel and remote annunciators during an active trouble, supervisory, or alarm event and acknowledges new event activations. | |
| Signal Silence | Alarm mode: Silences active notification appliances. Pressing Signal Silence a second time turns NACs back on. | |
| Drill | Initiates a drill confirmation. Pressing drill a second time turns off the drill function. | |
| Remote Disconnect | Dialer: Disables or enables dialer. Dialer set to modem only: Disables or enables the common alarm relay. | |
| Left arrow | Display mode: Moves the cursor to the left. Menu mode: Toggles between programming selections. | |
| Right arrow | Display mode: Moves the cursor to the right. Menu mode: Retrieves a programming option's sub menu and toggles between a programming option's selections. | |
| Up arrow | Display mode: Advances to the previous event. Menu mode: Moves the cursor up. | |
| Down arrow | Display mode: Advances to the next event. Menu mode: Moves the cursor down. | |
| Enter | Display mode: Displays selected event details. Menu mode: Retrieves a programming option's sub menu or jumps to the Save function in the menu. Entry mode: Enters the selected data into the system. | |
| Cancel | Display mode: Exits the detailed information display. Menu mode: Exits the current menu level. Entry mode: Clears the current entry. | |
| Menu | Display mode: Enters the menu mode Menu mode: Exits menu mode | |
| Space | Enters a space, such as a space between words. | |
| Alphanumeric keypad | Entry mode: Pressing a button once enters the number on the button. Pressing the button twice enters the secondary value. | |
| Programmable buttons | These buttons can be programmed to control outputs, disable devices or unlatch system outputs. The buttons can be labeled with a slip-in insert. | |

Page 2 of 10

DATA SHEET 85005-0130

Not to be used for installation purposes. Issue 7.1

System LEDs

| LED | Description | |
|------------|--|--|
| Alarm | Red LED. On steady when there is an active | |
| | alarm. | |
| Trouble | Yellow LED. Flashes when there is a fault on a | |
| | monitored circuit or system component, or when a | |
| | circuit is disabled. | |
| Sup | Yellow LED. On steady when there is an active | |
| | supervisory event. | |
| AC Power | Green LED. On when the panel has AC power. | |
| Disable | Yellow LED. Double-flashes when there is a dis- | |
| | abled circuit, alarm relay, or remote annunciator. | |
| Ground | Yellow LED. On steady during an active ground fault. | |
| Fault | | |
| Test | Yellow LED. Flashes when performing an audible | |
| | walk test. Steady indicates a silent test. | |
| Monitor | Yellow LED. On steady when there is an active | |
| | monitor event. | |
| Service | Yellow LED. Indicates that detector needs servicing. | |
| Detector | | |
| Signal | Yellow LED. On steady indicates that NAC circuits | |
| Silence | are turned off but the panel is still in alarm. | |
| Remote | Yellow LED. On steady indicates that the dialer | |
| Disconnect | is disabled or that the alarm relay is enabled or | |
| Dell | disabled when the dialer is set to modem only. | |
| Drill | Yellow LED. Indicates that the panel is in drill. | |
| Reset | Yellow LED. Indicates that the panel is resetting. | |
| Panel | Yellow LED. Indicates that the panel has been | |
| Silence | silenced during an active trouble, supervisory, or | |
| | alarm event and indicates that new event activa- | |
| | tions have been acknowledged. | |
| User Keys | Yellow LED. Programmable. | |

Panel Operation Options

| Language | English or French |
|----------------------------------|---|
| Marketplace | U.S. or Canada |
| AC fail delay | Off: Off-premise notification of an AC power failure is immediate. 1 to 15 hours: Delays the off-premise notification of an AC power failure by the time period selected. |
| Zone resound | On: NACs resound each time a device in the zone goes into alarm even if they were silenced Off: Inhibits the NACs from turning on again (after they were silenced) when a second device in the zone goes into alarm. |
| Reset inhibit after NACs turn on | Off: Panel reset is operational immediately. 1 minute: Panel reset is inhibited for one minute. |
| Auto signal silence | Off: Allows immediate silencing of signals from an off-normal condition using the Signal Silence button 5 to 30 minutes: Delays the silencing of signals from an off-normal condition by disabling the Signal Silence button for the time period selected. |
| Day start | Start time for daytime sensitivity |
| Night start | Start time for nighttime sensitivity |
| Date | U.S.: MM/DD/YYYY, Canada: DD/MM/YYYY |
| Sounder Base | Six configuration settings |
| Mapping | Disabled: Device mapping is not available Enabled: Device mapping is available |
| LCD banner | Banner text for line one and line two. Each line is capable of up to 20 characters. |
| Event notification | Zone: When a device is a member of a zone, only the zone information is sent to the LCD display, LEDs, printer, and dialer. Zone/device: Zone information is sent to the LCD display and LEDs. Device information is sent to the printer and dialer. Device: Only device information is reported. |

Programming

iO500 life safety systems are simple to set up, yet also offer advanced programming features that put these small building panels into a class of their own. The auto programming feature quickly gets the panel operational using factory default settings. Basic zone and point settings can be programmed easily through the front panel interface, so the system is up and running in no time.

For more advanced system configuration and correlation groups programming, iO500 systems interface to a PC running compatible iO-CU software. This option offers full system configuration in the familiar Windows® operating environment. Connection is typically made to a laptop through the panel's optional RS-232 communications port, which can also be used to connect a system printer.


Among the many innovative features of iO500 control panels is the optional network card. This module provides a standard 10/100 Base T Ethernet® network connection that permits access to the control panel from any remote location with the correct communications protocols. The connection can be used to download to the panel from the iO-CU, or upload and view system reports using the iO-CU.

Available system reports include:

- Correlation groups
- Device maintenance
- Internal status
- System status
- Dialer

- Device details
- History
- System configuration
- Walk test
- CO runtime

Dimensions



| Panel dimensions, in (cm) | | | | | | |
|---------------------------|----------------|---------------|---------------|----------------|-----------------|-----------------|
| Model | D1* | D2 | D3 | D4 | D5* | D6 |
| iO500 | 28.0 (71.1) | 3.85 (9.8) | 9.0 (22.8) | 22.0 (55.8) | 15.75 (40.0) | 10.25 (26.0) |

^{*} Add 1-1/2 in. (3.81 cm) to D1 and D5 dimensions for trim kit.

Wiring & Configuration


Notification appliance circuits (TB2)

iO500 control panels come equipped with four notification appliance circuits. Each circuit can be individually configured for continuous, temporal, synchronized, latching, and coded output.

| Circuit specifications | | | |
|------------------------|--|--|--|
| Circuit Type | 4 Class B or 2 Class A, 2.5 amps each | | |
| Voltage | 24 VFWR | | |
| Current | 6.0 A total, 2.5 A max. per circuit at 120/230 VAC 60 Hz 5.0 A total at 230VAC 50 Hz, 2.5 A max. per circuit | | |
| Impedance | 26 Ω total, 0.35 μF max | | |
| EOLR | 15 K O. ½ W | | |

Class B wiring NAC1 NAC1+ **EOLR** NAC2 \bigcirc \bigcirc NAC2+ TB2 NAC3 \bigcirc 0 NAC3+ FOI R \bigcirc NAC4 NAC4+

Marking indicates output signal polarity when the circuit is active. Polarity reverses when the circuit is not active. Wire notification appliances accordingly. Notification appliance polarity shown in active state.



Auxiliary & Smoke power outputs (TB3)

The control panel provides two auxiliary power outputs which can be used for powering ancillary equipment such as remote annunciators and two wire smoke detectors. Aux 2 can be software selected to operate continuous. The circuit is supervised for shorts and grounds.

Note: For a complete list of devices that can be connected to this circuit, refer to the iO Series compatibility list (p/n 3101064).

| Circuit specifications | | | |
|------------------------|--|--|--|
| Circuit voltage range | 21.9 to 28.3 V | | |
| Resettable circuit | 24 VDC nominal at 500 mA | | |
| (Aux power 2) | | | |
| Continuous circuit | 24 VDC nominal at 500 mA. Use this circuit for | | |
| (Aux power 1) | powering two-wire smoke detectors. | | |


Note: Any current above 0.5 amp connected to both Aux 1 and 2 will reduce the total available NAC power by that amount.

Signature Device loop

The system provides one device loop circuit with a total capacity of 125 detectors and 125 module addresses. The loop circuit is supervised for opens, shorts, and grounds.

The Signature Loop Controller uses broadcast polling and advanced communications formats to regularly check the entire device circuit for anomalies. If a change of state is detected at the circuit level, the Loop Controller then uses a direct address search to find the reporting device. This two-staged technique ensures that only new information is transmitted, thus allowing for a reduced baud rate while still achieving nearly instant device reporting.

| Circuit specifications | | |
|----------------------------|--|--|
| Device loops | 1 loop, expandable to 2, Class A or B, each loop supporting up to 250 device addresses | |
| Communication line voltage | Maximum 20 V peak-to-peak | |
| Circuit current | 0.5 A max | |
| Circuit impedance | 66Ω total, 0.5 μF, max | |
| Isolators | 64 maximum | |




Annunciator loop (TB4)

The control panel provides a connection for up to eight serially driven and supervised remote annunciators.

Circuit specifications

| Device loops | Class B (Style Y) or Class A (Style Z) |
|-------------------|--|
| Circuit voltage | 2.55 V |
| Circuit current | 30 mA max |
| Circuit impedance | Up to 8 annunciators or 4000 feet |



Alarm, trouble, and supervisory relay (TB3)

The trouble relay is normally-open, held closed, and opens on any trouble event or when the panel is de-energized. The supervisory relay is normally-open, and closes on any supervisory event. The alarm relay changes over on any alarm event.

Relay specifications


| | Alarm | Trouble | Supervisory |
|---------|-------------------------|-----------------------------------|-------------|
| Type | Form C | | Form A |
| Voltage | 24 VDC at 1 A resistive | resistive 24 VDC at 1 A resistive | |

Relay circuits can only be connected to power-limited sources.

Option Cards

iO500 panels are supported by a complete line of modules and related equipment that enhance performance and extend system capabilities. Option cards plug directly into the control panel main circuit board or are connected to it with a ribbon cable. After installation, terminals remain accessible. The cabinet provides ample room for wire routing, keeping wiring neat at all times.

SA-ETH Ethernet Interface Card



The SA-ETH card provides a standard 10/100 Base T Ethernet network connection for connecting to an intranet, a local network, or the Internet. The card can be used to download configuration programming from the iO-CU to the panel over the network.


The Ethernet card is installed on the plastic assembly and connects to the main circuit board via a ribbon cable.

| SA-ETH specifications | |
|------------------------------|------------------------------------|
| Ethernet | 10/100 Base T |
| Operating environment | |
| Temperature | 32 to 120°F (0 to 49°C) |
| Humidity | 0 to 93% RH, noncondensing at 90°F |
| | (32°C) |

XAL250 Loop Expander Card

The XAL250 Loop Expander Card provides an additional Signature Series device loop on the control panel. The card expands the control panel's device capacity to 500 total device addresses, 250 per loop. The card is compatible with Class B or Class A wiring. It is compatible with iO500 control panels only.


The loop expander card connects to connector J7 on the main circuit board.



| XAL250 specifications | |
|--------------------------|--|
| Device addresses on loop | 125 detectors and 125 modules |
| Wiring | Class B (Style Y) or Class A (Style Z) |
| Operating voltage | 20 V peak-to-peak |
| Operating current | 0.5 A total |
| Circuit impedance | 66 Ω, 0.5 μF, max |
| Terminal rating | 12 to 18 AWG (0.75 to 2.5 sq mm) |
| Operating environment | |
| Temperature | 32 to 120°F (0 to 49°C) |
| Humidity | 0 to 93% RH, noncondensing at 90°F |

SMK Smoke Power Converter


The SMK Smoke Power Converter Module provides a regulated power source for two-wire smoke circuits connected to a Signature data circuit. The SMK monitors the operating power from the power supply. When power begins to degrade, the SMK provides the necessary operating voltage to the two-wire smoke detection circuits.



| SMK specifications | |
|--------------------------------------|--|
| Input voltage | 21.9 to 28.3 VDC (not resettable) |
| Output voltage | 24 VDC nom. at 200 mA, max., special applications |
| Ground fault impedance | 10 k ohm |
| Operating environment Temperature | 32 to 120°F (0 to 49°C) |
| Humidity | 0 to 93% RH, noncondensing at 90°F (32°C) |
| Storage temperature | -4 to 140°F (-20 to 60°C) |
| Compatible electrical boxes | North American 4 inch square x 2-1/2 in. (64 mm) deep 2 gang box or Standard 4 in. square box 1-1/2 in. (38 mm) deep |
| Wire size | 14, 16, or 18 AWG wire (1.5, 1.0, or 0.75 sq. mm) (Sizes 16 and 18 AWG are preferred) |

SA-232 RS-232 interface

The SA-232 card provides an RS-232 interface with iO500 panels. It can be used for connecting a printer to the control panel to print system events. The card also can be used for connecting a computer to download a configuration program from the iO-CU to the control panel.




The RS-232 card is installed on the plastic assembly and connects to the main circuit board via a ribbon cable.

| SA-232 specifications | |
|-----------------------|---|
| Operating voltage | Standard EIA-232 |
| Terminal rating | 12 to 18 AWG (0.75 to 2.5 sq mm) |
| Operating environment | |
| Temperature | 32 to 120°F (0 to 49°C) |
| Humidity | 0 to 93% RH, noncondensing at 90°F (32°C) |

SA-DACT Dialer

The SA-DACT provides communications between the control panel and the central station over a telephone line system. It transmits system status changes (events) to a compatible digital alarm communicator receiver over the public switched telephone network. The dialer is capable of single, dual, or split reporting of events to two different account and telephone numbers. The modem feature of the SA-DACT can also be used for uploading and downloading panel configuration, history, and current status to a PC running the iO-CU.



The dialer phone lines connect to connectors on the dialer's main circuit board. Phone line 1 connects to connector J4 and phone line 2 connects to connector J1.

The SA-DACT queues messages and transmits them based on priority (alarm, supervisory, trouble, and monitor). Activations are transmitted before restorations.

The SA-DACT is installed on the plastic assembly and connects to the main circuit board via a ribbon cable.

| SA-DACT specifications | |
|-------------------------------|--|
| Phone line type | One or two loop-start lines on a public, |
| | switched network |
| Phone line connector | RJ-31/38X (C31/38X) |
| Communication formats | Contact ID (SIA DC-05) |
| Operating environment | |
| Temperature | 32 to 120°F (0 to 49°C) |
| Humidity | 0 to 93% RH, noncondensing at 90°F |
| | (32°C) |

| Compatible DACRs | | |
|------------------|---------------|------------|
| Receiver | Models | Formats |
| Ademco | 685 | Contact ID |
| FBII | CP220 | Contact ID |
| Osborne-Hoffman | OH 2000 | Contact ID |
| Radionics | D6600 | Contact ID |
| Silent Knight | 9800 | Contact ID |
| Sur-Gard | SG-MLR1, MLR2 | Contact ID |


SIGA-REL Releasing Module

The SIGA-REL is an analog addressable module that communicates directly with the fire alarm panel Signature loop controller. The SIGA-REL controls sprinkler, pre-action and deluge systems, and may also be used to release extinguishing agents such as $\rm CO_2$, Halon, or foam. The module is easily configured in the field and offers a wide range of options that ensure dependable service, while preventing the unnecessary release of extinguishing agent.

SIGA-REL specifications

| Power riser | Input voltage Supervisory current Riser input current Alarm | 24 Vdc (power limited) 25 mA, max. 4 amps maximum 170 mA min.; 4 A max. |
|------------------------------------|---|---|
| Release circuits | Output rating Valves per circuit Max. supervisory current Nominal supervisory current Supervisory voltage End of line device | 2 A @ 24 Vdc (per circuit) 4 valves, max. 0.4 mA (short circuit) 0.18 mA 26 Vdc, max. (open circuit) 47k Ohm EOL |
| Pre-release alarm circuits | Output rating Max. supervisory current Nominal supervisory current Supervisory voltage End of line device | 2 A @ 24 Vdc (for each circuit) 0.4 mA (short circuit) 0.18 mA 26 Vdc, max. (open circuit) 47k Ohm resistor |
| Manual release input circuit | Max. supervisory current Nominal supervisory current Supervisory voltage End of line device Circuit type Circuit capacitance | 0.4 mA (short circuit) 0.18 mA 26 Vdc, max. (open circuit) 47k Ohm resistor Class B N.O. latching 0.1 µF, max |
| Abort circuit | Max. supervisory current Nominal supervisory current Supervisory voltage End of line device Circuit type Circuit capacitance | 0.4 mA (short circuit) 0.18 mA 26 Vdc, max. (open circuit 47k Ohm resistor Class B N.O. non- latching 0.1 µF, max |
| First alarm output relay | Contact rating | 3 A @ 24 Vdc (0.6 power factor) Form C |
| Signature Data line | Operating voltage Supervisory current Alarm current | 5.2 to 19.95 Vdc 1000 μA 1000 μA |

Note: Output circuits are power-limited when the riser circuit is power-limited.



For detailed specification and ordering information on the SIGA-REL, refer to Data Sheet 85001-0531 -- Releasing Module.

Specifications

| 1 | |
|-------------------------------------|---|
| Device loops | 1 loop, expandable to 2, Class A or B, each loop supporting up to 250 device addresses |
| NAC circuits | 4 Class B or 2 Class A, 2.5 amps each |
| Power supply | 6.0 A total, 2.5 A max. per circuit at 120/230 VAC 60 Hz 5.0 A total at 230VAC 50 Hz, 2.5 A max. per |
| | circuit |
| | 0.5 amps aux power |
| NAC Operating voltage | 24 VDC. NAC minimum voltage: 19.5 VDC @ 20.4 V battery voltage |
| Loop circuit operating voltage | 20 V peak-to-peak |
| SLC Primary power | 120 VAC, 60 Hz, 230 VAC 50-60 Hz |
| Aux Power 1 (Continuous circuit) | 24 VDC nominal at 500 mA. A SMK module is required when using the SIGA-UM module to support two-wire smoke detectors. |
| Aux Power 2 | 24 VDC nominal at 500 mA |
| (Resettable circuit) | |
| Auxiliary output | 19 to 25.7 VDC |
| Base panel | Standby: 172 mA |
| current draw | Alarm: 267 mA |
| Panel History Log | 1,000 events |
| | |

| Battery placement | iO500 cabinets accommodate up to 18 A/H |
|---------------------|---|
| | batteries. Use a external cabinet for larger battery |
| | sizes. |
| Batteries | Batteries must be sealed lead acid type only. |
| | Maximum charging capacity = 26 Ah. |
| Loop circuit | Maximum loop resistance: 66 Ω. Maximum loop |
| | capacitance: 0.5 µF. Style 4, 6, and 7 wiring. 64 |
| | isolators maximum. |
| SIGA-UM/SIGA- | 1.5 mA (see the UL and ULC compatibility list for |
| MAB | for the maximum quantity of detectors per circuit) |
| Compatibility ID | 100 |
| Alarm contact | Form C 24 VDC @ 1 A (resistive load) |
| Trouble contact | Form C 24 VDC @ 1 A (resistive load) |
| Supervisory contact | Form A 24 VDC @ 1 A (resistive load) |
| Environmental | Temperature: 0 to 49°C (32 to 120°F). |
| | Humidity: 0 to 93% RH, noncondensing |
| Terminal rating | All terminals rated for 12 to 18 AWG (0.75 to 2.5 mm ²) |
| Serial | Voltage: 2.55 V. Current: 30 mA max |
| communications | |
| Remote annunciator | 8 drops max, RS-485 Class A or B |
| Input zones | 32 max. |
| Agency Listing | UL864, UL2017, CSFM, ULC and NYFD #6020, |
| | FM approved |
| | |

Ordering Information

| Part | Description | | |
|---|--|--|--|
| iO500 Intelligent Multi-Loop Analog Systems | | | |
| iO500G | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure, 115 Vac, English. | | |
| iO500G-2 | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure, 230 Vac, English. | | |
| iO500GC | Canada only: 1 Loop system, 500 point capacity, 4 NACs, 16-zone LED display, grey door, surface mount, 115 Vac, English. | | |
| iO500G-F | Canada only: 1 Loop system, 500 point capacity, 4 NACs, 16-zone LED display, grey door, surface mount, 115VAC, French. | | |
| iO500GD | 1 Loop system, 500 point capacity, two-line dialer, 4 NACs, Gray door, surface mount enclosure, 115VAC transformer, English. | | |
| iO500R | 1 Loop system, 500 point capacity, 4 NACs, red Door, surface mount enclosure, 115VAC transformer, English. | | |
| iO500R-2 | 1 Loop system, 500 point capacity, 4 NACs, red door, surface mount enclosure, 230VAC transformer, English. | | |
| iO500RD | 1 Loop system, 500 point capacity, two-line dialer, 4 NACs, Red Door, surface mount enclosure, 115VAC transformer, English. | | |
| iO500G-SP | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure, 115vac, Spanish. | | |
| iO500G-2-SP | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure, 230vac, Spanish. | | |
| iO500G-PG | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure, 115vac, Portuguese. | | |
| iO500G-2-PG | 1 Loop system, 500 point capacity, 4 NACs, gray door, surface mount enclosure,, 230vac, Portuguese. | | |
| SA-TRIM2 | Flush mount trim, black | | |

Replacement Electronics 500elec-iO Replacement electronics kit, complete motherboard and user interface, English 500elec-iO-SP Replacement electronics kit, complete motherboard and user interface, Spanish 500elec-iO-PG Replacement electronics kit, complete motherboard and user interface, Portuguese

500elec-iO-FR Replacement electronics kit, complete motherboard and user interface, Canadian French

| Option Cards | |
|---------------------|---|
| SA-DACT | Dual Line Dialer/Modem, supports Contact ID, mounts in cabinet on base plate. |
| SA-232 | Serial Port (RS-232), for connection to printers & computers, mounts in cabinet to base plate |
| SA-ETH | Ethernet Port, Slave, mounts in cabinet on base plate. |
| XAL250 | Signature Loop Expansion Module. Adds second loop to iO500 systems, 250 point capacity. Mounts in cabinet on main board. |
| D16L-iO-2 | LED Annunciator module, 16 X 2-LED zones (4 programmable for sup). Mounts in cabinet to right of LCD display for zones 17-32. |
| D16L-iO-1 | LED Annunciator module, 16 X 2-LED zones (4 programmable for sup). Mounts in cabinet to left of LCD display for zones 1-16. |
| D8RY-iO-2 | Canada only: LED Annunciator module, two LEDs per zone, 16 zones (4 alarm only, 8 supervisory only, 4 alarm or supervisory). |
| | Mounts in cabinet to right of LCD display for zones 17-32. |
| D8RY-iO-1 | Canada only: LED Annunciator module, two LEDs per zone, 16 zones (4 alarm only, 8 supervisory only, 4 alarm or supervisory). |
| | Mounts in cabinet to left of LCD display for zones 1-16. |

| Remote Ann | nunciators (refer to Data Sheet 85005-0128) |
|-------------------|---|
| | Annunciators (mount to standard 4" square electrical box) |
| RLCD | Remote Annunciator, 4X20 LCD & Common Indicators for displaying system status. Gray housing. |
| RLCD-R | Remote Annunciator, 4X20 LCD & Common Indicators for displaying system status. Red housing. |
| RLCD-C | Remote Annunciator, 4X20 LCD. Common controls and status indicators. Gray housing. |
| RLCD-CR | Remote Annunciator, 4X20 LCD. Common controls and status indicators. Red housing. |
| RLCD-SP | Remote Annunciator, 4X20 LCD. Common system status indicators. White housing. Spanish. |
| RLCD-PG | Remote Annunciator, 4X20 LCD. Common system status indicators. White housing. Portuguese. |
| RLCD-C-SP | Remote Annunciator, 4X20 LCD. Common controls and status indicators. White housing. Spanish. |
| RLCD-C-PG | Remote Annunciator, 4X20 LCD. Common controls and status indicators. White housing. Portuguese. |
| RLED-C-SP | Remote Annunciator, common controls and status indicators. 16 groups w/2 LEDs each for zone display. White housing. Spanish. |
| RLED-C-PG | Remote Annunciator, common controls and status indicators. 16 groups w/2 LEDs each for zone display. White housing. Portuguese. |
| GCI | Graphic Annunciator Driver Master for R-Series annunciators. Outputs for 32 LEDs, connection to common control switches and LEDs. |
| GCIX | Graphic Annunciator Driver Expander for use with GCI Masters. Outputs for 48 LEDs, 24 switch inputs for R-Series annunciators. |
| For French com | mon control, add suffix F to model number. |
| LED Remote | Annunciators & Expander (mount to standard 4" square electrical box) |
| RLED-C | Remote Annunciator. Common controls and status indicators with 16 X 2-LED groups for zone display. Gray housing. |
| RLED-CF | Remote Annunciator. Common controls and status indicators with 16 X 2-LED groups for zone display. Gray housing, French. |
| RLED-CR | Remote Annunciator. Common controls and status indicators with 16 X 2-LED groups for zone display. Red housing. |
| RLED24 | Remote Annunciator Zone expander. 24 X 2-LED groups with custom label areas for display of alarm and trouble. Gray housing. |
| RLED24R | Remote Annunciator Zone expander. 24 X 2-LED groups with custom label areas for display of alarm and trouble. Red housing. |
| Remote Anni | unciator Cabinets & Accessories |
| RA-ENC1 | Remote Annunciator Enclosure, key locked with plexiglass window for one RLCD(C) or RLED(C). |
| RA-ENC2 | Remote Annunciator Enclosure, key locked with plexiglass window with space for 2 of either RLCDx, RLEDx or RLED24. |
| RA-ENC3 | Remote Annunciator Enclosure, key locked with plexiglass window with space for 3 of either RLCDx, RLEDx or RLED25. |
| RKEY | Keyswitch, single gang, provides key operated enable or disable of common controls on RLCD or RLED units. |
| LSRA-SB | Surface Mount Box - for R Series single units. |
| Programmir | ig Tools |
| iO-CU | EST Series configuration and diagnostics utility. |
| 260097 | RS232 cable, 4 conductor, DB9 PC interface |

Intelligent Analog Addressable Devices & Accessories Part # Description

| Part # | Description | Ship wt. |
|-------------------|---|------------|
| | | |
| Intelligent Detec | | |
| SIGA2-PHCOS | Intelligent Multisensor Photoelectric/Heat Detector with carbon monoxide sensor | |
| SIGA2-PHS | Intelligent Multisensor Photoelectric/Heat Detector | |
| SIGA2-PHSB | Intelligent 4D Multisensor Detector (Black) - UL/ULC Listed | |
| SIGA2-PCOS | Intelligent Photoelectric Detector with carbon monoxide sensor | |
| SIGA2-PS | Intelligent Photoelectric Detector | 0.4 (0.16) |
| SIGA2-HRS | Intelligent combination fixed temperature/rate-of-rise heat detector | |
| SIGA2-HFS | Intelligent fixed temperature heat detector | |
| SIGA2-HCOS | Intelligent fixed temperature heat detector with CO sensor | |
| SIGA2-COS | Intelligent Carbon Monoxide Detector | |
| SIGA-HFS | Intelligent Fixed Temperature Heat Detector | |
| SIGA-HRS | Intelligent Fixed Temperature/Rate-of-Rise Heat Detector | |
| SIGA-IPHS | Intelligent 4D Multisensor Detector | |
| SIGA-IPHSB | Intelligent 4D Multisensor Detector (Black) | 0.5 (0.23) |
| SIGA-PHS | Intelligent 3D Multisensor Detector | |
| SIGA-PS | Intelligent Photoelectric Detector | |
| SIGA-SD | Intelligent Duct Detector | |
| SIGA-SB | Detector Mounting Base | |
| SIGA-SB4 | 4-inch Detector Mounting Base c/w SIGA-TS Trim Skirt | |
| SIGA-RB | Detector Mounting Base w/Relay | |
| SIGA-RB4 | 4-inch Detector Mounting Base /w Relay c/w SIGA-TS Trim Skirt | 0.2 (0.09) |
| SIGA-IB | Detector Mounting Base w/Fault Isolator | |
| SIGA-IB4 | 4-inch Detector Mounting Base w/ Fault Isolator c/w SIGA-TS Trim Skirt | |
| SIGA-LED | Remote Alarm LED | |
| SIGA-AB4G | Audible (Sounder) Base | 0.3 (0.15) |

| SIGA-TS4 | Trim Skirt (supplied with 4-inch bases) | 0.1 (.04) |
|------------------------|---|-------------|
| SIGA-AB4GT | Audible (Sounder) Base for CO and Fire Detectors | 0.3 (0.15) |
| SIGA-TCDR | Temporal Pattern Generator | 0.3 (0.15) |
| Modules | | |
| SIGA-CC1 | Single Input Signal Module (Standard Mount) | 0.5 (0.23) |
| SIGA-MCC1 | Single Input Signal Module (UIO Mount) | 0.18 (0.08) |
| SIGA-CC1S | Synchronization Output Module (Standard Mount) | 0.5 (0.23) |
| SIGA-MCC1S | Synchronization Output Module (UIO Mount) | 0.18 (0.08) |
| SIGA-CC2 | Dual Input Signal Module (Standard Mount) | 0.5 (0.23) |
| SIGA-MCC2 | Dual Input Signal Module (UIO Mount) | 0.18 (0.08) |
| SIGA-CR | Control Relay Module (Standard Mount) | 0.4 (0.15) |
| SIGA-MCR | Control Relay Module (UIO Mount) | 0.18 (0.08) |
| SIGA-CRR | Polarity Reversal Relay Module (Standard Mount) | 0.4 (0.15) |
| SIGA-MCRR | Polarity Reversal Relay Module (UIO Mount) | 0.18 (0.08) |
| SIGA-RM1 | Riser Monitor Module (Standard Mount) | 0.16 (0.06) |
| SIGA-NRM1 | Riser Monitor Module (Plug-in) | 0.3 (0.23) |
| SIGA-IVINIVI | Input/Output Module (Standard Mount) | 0.18 (0.08) |
| SIGA-MIO | Input/Output Module (Plug-in) | 0.22 (0.10) |
| SIGA-IVIIO SIGA-MAB | Universal Class A/B Module (Plug-in) | 0.22 (0.10) |
| SIGA-IVIAD SIGA-CT1 | Single Input Module | 0.16 (0.08) |
| SIGA-CT1 | Dual Input Module | , , |
| SIGA-C12 | Dual Input Plug-in (UIO) Module | 0.4 (0.15) |
| SIGA-IVICTZ SIGA-IM | Fault Isolator Module | 0.1 (0.05) |
| | | 0.5 (0.23) |
| SIGA-MM1 | Monitor Module | 0.4 (.15) |
| SIGA-WTM | Waterflow/Tamper Module | 0.4 (.15) |
| SMK | Smoke Power Converter Module | 0.4 (0.15) |
| SIGA-UIO2R | Universal Module Board w/Riser Inputs - Two Module Positions | 0.32 (0.15) |
| SIGA-UIO6R | Universal Module Board w/Riser Inputs - Six Module Positions | 0.62 (0.28) |
| SIGA-UIO6 | Universal Module Board - Six Module Positions | 0.56 (0.25) |
| SIGA-REL | Analog addressable releasing module | 0.5 (0.23) |
| 276A-REL | Manual releasing station (single-action). English markings, black text on yellow polycarbonate body. | 1.0 (0.45) |
| 278A-REL RELA-ABT | Manual releasing station (double-action). English markings, black text on yellow polycarbonate body. Manual Abort Station. English markings, black text on yellow polycarbonate body. | 1.0 (0.45) |
| RELA-ABT | Service Disconnect Switch. One n/c contact and one n/o contact. English markings, white text on blue | 1.0 (0.45) |
| RELA-EOL | polycarbonate body. Polarized end-of-line relay. English markings on stainless steel cover. | 0.2 (0.1) |
| ILLA-LOL | 1 Garzed end-Grille reay. English markings on stainless steel cover. | 0.2 (0.1) |
| Accessories | | |
| GCI | Graphic Annunciator Driver, provides outputs for common indicators and 32 alarm/supv zones as well as inputs for common switches. Provided with a snap track for mounting in custom graphic enclosures. | |
| CTM | City Tie Module. Provides connection to a local energy fire alarm box. | 0.6 (0.3) |
| RPM | Reverse Polarity Module | 3.0 (1.36) |
| 3C-1 | Battery Cabinet. 14.0" x 18.25" x 7.25". Holds 2 12V24A batteries. | 50.0 (22.7) |
| 3C-1R | Battery Cabinet - Red. 14.0" x 18.25" x 7.25". Holds 2 12V24A batteries. | 50.0 (22.7) |
| BC-1EQ | Seismic hardening Kit for iO series panels. Includes battery hardening for BC-1 enclosure and components to harden panel internal components. See note below. | |
| MFC-A | Multifunction Fire Cabinet, 8" x 14" x 3.5" - RED. | 20.6 (9.4) |
| DT 40 | Onton Piston Posture della | 00 0 (40 0) |

PT-1S Note:

For earthquake anchorage, including detailed mounting weights and center of gravity detail, please refer to Seismic Application Guide 3101676-EN. Approval of panel anchorage to site structure may require local AHJ, structural, or civil engineer review.

Standby batteries must be mounted externally from fire panel in separately mounted BC-1 enclosure. Order BC-1 and BC-1EQ separately.

System Printer - Desktop style.

36.6 (16.6)



Contact us...

Email: edwards.fire@fs.utc.com Web: <u>www.est-fire.com</u>

EST is an **EDWARDS** brand.

1016 Corporate Park Drive Mebane, NC 27302

In Canada, contact Chubb Edwards... Email: inquiries@chubbedwards.com Web: <u>www.chubbedwards.com</u>

© 2013 UTC Fire & Security Americas Corporation, Inc. All rights reserved. Specifications subject to change without notice. Edwards is part of UTC Climate, Controls & Security, a unit of United Technologies Corporation.