



TRUSS HOLD-DOWN SCHEDULE		
TRUSS	SIMPSON HOLD-DOWN (*)	REMARKS
T-1	(2) - H10's	
T-2	H1	
T-3	(2) - H10's	
T-3A	(2) - T822	PROVIDE WOOD BLOCKING WITHIN STEEL BEAM DEPTH
GT-1	(3) - T822	PROVIDE WOOD BLOCKING WITHIN STEEL BEAM DEPTH

(*) OR EQUIVALENT



DIAGONAL BRACING OF TOP CHORD OF BASE TRUSS AT PIGGY BACK TRUSS LOCATIONS

CONTRACTOR SHALL REFERENCE AND CONFORM TO BUILDING COMPONENT SAFETY INFORMATION BC81 1-03 GUIDE TO GOOD PRACTICE FOR HANDLING, INSTALLING & BRACING OF METAL PLATE CONNECTED WOOD TRUSSES (JOINTLY PRODUCED BY WOOD TRUSS COUNCIL OF AMERICA AND TRUSS PLATE INSTITUTE).

NOTES:

- SEE #10 FOR ADDITIONAL PREFABRICATED WOOD TRUSS NOTES.
- ADD PERMANENT DIAGONAL BRACING AS SHOWN IN PLAN IN ADDITION TO ALL OTHER TEMPORARY AND PERMANENT BRACING REQUIRED.
- WOOD TRUSS DESIGNER IS RESPONSIBLE FOR THE DESIGN OF WOOD TRUSS TO WOOD TRUSS CONNECTIONS, INCLUDING LOAD COMBINATIONS WITH WIND AND GRAVITY.
- TRUSS DESIGNER IS RESPONSIBLE FOR LAY-ON TRUSS FRAMING AND THEIR CONNECTIONS.
- WHERE PERMANENT WEB BRACING IS REQUIRED BY THE TRUSS DESIGNER, CONTRACTOR SHALL DIAGONALLY BRACE THE WEB MEMBERS IN CONFORMANCE WITH BC81-B3, WEB MEMBER PERMANENT BRACING (PAGES B1 THRU B3 OF BC81 1-03). CONTRACTOR SHALL PROVIDE CONTINUOUS LATERAL BRACING (CLB) AT LOCATIONS NOTED BY TRUSS DESIGNER. SEE OTHER SECTIONS OF BC81 1-03 FOR ADDITIONAL WEB MEMBER DIAGONAL BRACING.
- WHERE PERMANENT BOTTOM CHORD BRACING IS REQUIRED BY THE TRUSS DESIGNER, CONTRACTOR SHALL PERMANENTLY BRACE THE BOTTOM CHORDS OF THE TRUSSES WITH DIAGONAL BRACING PER BC81-B1, PAGE 5. SEE OTHER SECTIONS OF BC81 1-03 FOR ADDITIONAL BOTTOM CHORD BRACING REQUIREMENTS.


TYP WOOD TRUSS DETAILS

ROOF FRAMING PLAN



NOTES:

- SU-1X DENOTES SHEAR WALL, ALONG APPLICABLE GRID LINE, SEE SHEAR WALL SCHEDULES ON DWGS. 04-06. SHEAR WALLS EXTEND UP TO ROOF DIAPHRAGM, TYP.
- PROVIDE TRUSS HOLD-DOWNS AT EACH END OF TRUSSES PER TRUSS HOLD-DOWN SCHEDULE.
- SEE TYPICAL WOOD TRUSS NOTES THIS DRAWING. FABRICATOR SHALL PROVIDE A ONE PIECE TRUSS (IF POSSIBLE).
- SEE DRAWINGS 02 FOR WOOD TRUSS DIAGRAMS.
- EXTERIOR WALLS ARE 2x6 STUDS @ 16" O.C. HOWEVER, ADDITIONAL STUDS REQUIRED BENEATH ROOF TRUSSES WITH LENGTHS GREATER THAN 6'-0". ADDITIONAL STUDS TO BE ALIGNED WITH ROOF TRUSSES AND CONTINUOUS DOWN TO FOUNDATION WALL.
- PROVIDE (4)-2x6 BUILT-UP COLUMNS BENEATH GIRDER TRUSSES, TYP. ANCHOR THRU-FLOOR w/ SIMPSON PHD2-8D85's, OR EQUIVALENT, PER 3/8" TYP. PROVIDE SOLID BLOCKING THROUGH FLOOR DEPTH, TYP.



PORT CITY ARCHITECTURE

65 NEWBURY STREET
PORTLAND, ME 04101
207.761.9000
fax: 207.761.2010
info@portcityarch.com

© COPYRIGHT

Reuse or reproduction of the contents of this document is not permitted without written permission of PORT CITY ARCHITECTURE PA

GUILFORD COURT
157 York Street
PORTLAND, ME

JOB: 03126

ISSUE DATE

FRELIM	-
DD	-
BID	03.11.03
C.D.'s	01.05.04
REVISION	08.25.04
PRINT	06.18.04

DRAWN BY MAC

CHECK BY ACH

ROOF FRAMING

S-7