




SUBMITTAL DOCUMENTS

FOR

LONGFELLOW COMMONS

PORTLAND, ME



Serving Maine Since 1942

**Eastern Fire Protection Co.
Eastern Fire Services, Inc.**

RESIDENTIAL * COMMERCIAL * INDUSTRIAL
24 HOUR SERVICE

Installation/Design/Testing/Inspections/Maintenance

<p>Auburn 207-784-1507 800-434-4337 170 Kittyhawk Ave.</p>	<p>FIRE SPRINKLER FIRE ALARM CLEAN AGENT GAS DETECTION</p>	<p>Bangor 207-942-8014 800-866-8014 408 Harlow St.</p>
<p>SIEMENS Fire Alarm</p>	<p>www.efp-efs.com</p>	<p>ENMET Gas Detection</p>

CONTRACT WITH: WESTON ASSOCIATES MGMT

TABLE OF CONTENTS

CATALOG CUTS AND DESCRIPTIVE LITERATURE

1. SCOPE OF WORK
2. I/O DIAGRAMS
 - a. PHASE I
 - b. PHASE II
3. SIEMENS EQUIPMENT CATALOG CUTS
 - a. FS-250 – FIRE ALARM CONTROL PANEL
 - b. FS-DACT – DIGITAL COMMUNICATOR
 - c. FS-RD2 – REMOTE ANNUNCIATOR
 - d. HFP-II – ADDRESSABLE SMOKE DETECTOR
 - e. HFPT-II – ADDRESSABLE HEAT DETECTOR
 - f. DB-II – DETECTOR BASE
 - g. DT-135R – 135 FT/ROR HEAT DETECTOR
 - h. MSM-KD – MANUAL PULL STATION
 - i. HTRI-M – SINGLE INPUT MINI MONITOR MODULE
 - j. HTRI-S – SINGLE INPUT MONITOR MODULE
 - k. ZH-MC-R – FIRE ALARM HORN/STROBE
 - l. ZR-MC-R – FIRE ALARM STROBE
 - m. ZH-R – FIRE ALARM HORN
4. VOLTAGE DROP AND BATTERY CALCULATIONS
5. SYSTEM DRAWINGS

End of Table of Contents

To: Portland Fire Department

From: Colby Malcolm

Re: Longfellow Commons Scope of Work

Longfellow Commons is an existing apartment building comprised of 44 dwelling units from 1 – 2 bedrooms. The property is equipped with an existing Fire Alarm System comprised of detection in common areas and occupant notification. The building has an existing automatic sprinkler system that is monitored by the current Fire Alarm system, however only common areas sprinklered. The documentation enclosed in this package shows the proposal to upgrade the Fire Alarm throughout the entire building in a two phase project.

Phase 1: Phase 1 is to replace the existing conventional FACP with the proposed new addressable FACP. Conventional zone modules will be used to monitor existing devices for alarm, trouble, and supervisory while installation of new addressable devices is going on.

Phase II: Phase II is to install new addressable devices throughout the building for current code compliance. Once new devices are in place the old conventional ones will be disconnected and the new ones connected, finalizing the transition to a new complete fire alarm system in compliance with the City of Portland fire alarm requirements for existing apartment buildings.

.

If there are any questions about the scope of work or any enclosed documentation please feel free to call or email at any time. Thank you

Colby Malcolm

Eastern Fire Services

(207) 784-1507 ext. 242

malcolmcr@efp-efs.com

LONGFELLOW COMMONS ALARM INPUT/OUTPUT MATRIX PHASE I

System Inputs	Activate Alarm LED on FACP	Activate Local Alarm Audible Signal	Activate Supervisory LED on FACP	Activate Local Supervisory Audible Signal	Activate Trouble LED on FACP	Indicate Local Trouble Audible Signal	Activate System Status & Location	Activate Audible/Visual Evacuation Signals in Common Areas	Activate Alarm LED on FACP Display	Activate Remote Audible Signals in Dwelling Units	Activate Supervisory LED on Remote Annunciator	Indicate Trouble Supervisory Audible Signal	Transmit System Status and Location	Transmit Alarm Status and Location	Transmit Supervisory Signal to Central Station	Close Fire Doors	Activate Elevator Recall Functions
Manual Pull Station	X	X				X	X								X		X
Smoke Detector	X	X				X	X								X		X
Heat Detector	X	X				X	X								X		X
Low Battery				X	X	X									X		
Loss of AC Power				X	X	X									X		
Open Circuit				X	X	X									X		
Short Circuit				X	X	X									X		
Ground Fault				X	X	X									X		
Sprinkler Tamper			X	X										X			
Sprinkler Flow			X	X			X	X					X			X	
Elevator Smokes			X	X			X	X					X		X	X	

LONGFELLOW COMMONS ALARM INPUT/OUTPUT MATRIX PHASE II

System Inputs	Activate Alarm LED on FACP	Activate Local Alarm Audible Signal	Activate Supervisory LED on FACP	Activate Local Supervisory Audible Signal	Activate Trouble LED on FACP	Indicate System Status & Location on FACP	Activate Audible/Visual Evacuation Signals in Common Areas	Activate Alarm LED on Remote Annunciator	Activate Supervisory LED on Remote Annunciator	Indicate Trouble LED on Remote Annunciator	Transmit Alarm Status and Location on Remote Display	Transmit Alarm Audible Signal	Transmit Supervisory Status and Location on Remote Display	Transmit Trouble Signal to Central Station	Close Fire Doors	Activate Elevator Recall Functions
Manual Pull Station	X	X				X	X		X	X				X		X
Smoke Detector	X	X				X	X		X	X				X		X
Heat Detector	X	X				X	X		X	X				X		X
Low Battery				X	X	X					X	X				X
Loss of AC Power				X	X	X					X	X				X
Open Circuit				X	X	X					X	X				X
Short Circuit				X	X	X					X	X				X
Ground Fault				X	X	X					X	X				X
Sprinkler Tamper			X	X						X	X				X	
Sprinkler Flow			X	X			X	X	X	X				X		X
Elevator Smokes			X	X			X	X	X	X				X		X

FireSeeker Fire Alarm System

Addressable Fire Alarm Control Panel Model FS-250

ARCHITECT AND ENGINEER SPECIFICATIONS

- One (1) Intelligent Signaling Line Circuit (Style 4 or Style 6)
- SLC loop supports up to 252 addressable Inputs and signal / relay outputs
— 504 total inputs / outputs
- *SureWire™* polarity insensitive addressable-device loop wiring
- Devices operate on standard wire; no twist or shield required
- *FirePrint™* application-specific fire detection
- Four (4) Class B – Style Y / Two (2) Class A – Style Z notification-appliance circuits
- Up to 6 Amps. – NAC Power
- Built-in strobe synchronization protocol
- 80-character backlit LCD display
- One-man walk test (Silent or Audible)
- Auto Program Feature makes system commissioning more efficient
- Up to four (4) remote LCD displays with control capabilities
- Easily programmable from front keypad or Windows®-based PC configuration tool (not required)
- Maintenance and technician-level passwords for added security
- Optional internal DACT and city-tie module
- Up to 2,000-event history log
- Manual fan-restart feature



- Made in the USA, ISO 9001 quality crafted
- Three (3) on-board, programmable relays, plus one (1) non-programmable *Fail / Safe* relay for *Trouble* events
- **UL 864 9th Edition Listed;**
FM, CSFM & NYMEA Approved

Product Overview

The Model FS-250 Addressable Fire Alarm Control Panel is a low-cost, small panel suited for standalone operation in small-to-medium-sized facilities. Model FS-250 features a single, addressable input-device circuit and four (4) notification-appliance circuits. The Model FS-250 system is available in either a black or red enclosure, with operating controls and indicators behind a locked door. Model FS-250 is **UL 864 9th Edition Listed** by Underwriters Laboratories.

Specifications

Model FS-250 indicates *Alarm*, *Trouble* and *Supervisory* conditions with an 80-character backlit LCD display and integral system status LEDs. *Acknowledge*;

Alarm Silence and *System Reset* commands are accomplished with built-in membrane control buttons. Basic user and maintenance-level functions, such as *Viewing History* or *System Enable / Disable*, are also accomplished through the membrane control buttons. Maintenance-level functions are password protected.

The main system for Model FS-250 can support up to 38 AH battery sets – up to 12 AH will fit inside the enclosure.

The basic Model FS-250 fire alarm control panel features a single, addressable signaling line circuit (Style 4 or 6); capable of supporting up to 252 addressable input devices – whether they are detectors, manual pull stations, or contact monitoring points.

FireSeeker Fire Alarm Control Panel (FS-250) **4306**

Specifications — (continued)

Each detector can also have an optional, audible-detector base, relay-detector base or remote lamp. These auxiliary devices are completely controlled through logic, and are not required to activate simultaneously with the detector.

The Model FS-250 system also has four (4) Class B notification-appliance circuits built into the main board, which can be configured as two (2) Class A circuits. Each circuit has a capacity of 1.5 amps of 24VDC for powering horns, strobes, chimes, and other notification appliances, and the total base-system capacity for the four (4) circuits is 3.0 amps — expandable to 6A max. Each NAC is fully programmable, and supports standard and custom-coded outputs of audible devices.

Model FS-250 control panel has three (3) programmable 'Form C' dry-contact relays. One (1) additional non-programmable 'Form C' dry-contact relay is provided that activates only on *Trouble* events — operating in *Fail / Safe* mode in order to activate if there is a system power failure. Each relay is rated at 1 amp @ 28VDC. Up to 0.5A auxiliary 24VDC power is also available on the Model FS-250 main board.

Minimum Control Unit Configuration

Intelligent Signaling Line Circuit (SLC)

The main termination board for Model FS-250 has addressable-loop interface circuitry supporting one (1) SLC loop. Devices are polarity insensitive, and can operate on untwisted, unshielded wire.

Notification Appliance Circuits (NAC)

The Model FS-250 base panel has four (4) independent NACs. Each circuit can be configured to give continuous output, or one (1) of five (5) sounding patterns. NACs can be configured as: two (2) 'Class A — Style Z' or four (4) 'Class B — Style Y.'

Dry Contacts

Three (3) programmable 'Form C' dry-contact relays are provided on the Model FS-250 fire alarm control panel. One (1) additional 'Form C' dry-contact relay is provided that activates only on *Trouble* events. This relay operates in *Fail / Safe* mode, in order to activate if there is a power failure of the Model FS-250 system.

Power Supply

This component provides all operating power to the Model FS-250 panel for *Standby* and *Alarm* conditions.

Optional Control Unit Configuration

Digital-Alarm Communication Transmitter (FS-DACT)

Communication between the FS-250 fire alarm control panel and a monitoring station is accomplished with Model FS-DACT, which supports two (2) lines and two (2) accounts, and can transmit serial data, by point, to the central or remote station.

Communication protocols available include:

- SIA DCS 8
- SIA DCS 20
- Ademco Contact ID
- 3/1 1400 Hz
- 3/1 2300 Hz
- 4/2 1400 Hz
- 4/2 2300 Hz

Model FS-DACT mounts within the Model FS-250 fire alarm control panel. Neither an external enclosure nor wires are required between the panel and the dialer. Programming of account and dialing data is done as part of the system configuration, and no external programmer for the dialer is required.

Municipal Tie / Leased Line (FS-MT)

For installations that require connection to a municipal call box or a leased line, the municipal tie module (Model FS-MT) is used. Model FS-MT provides a local-energy output for municipal call-box connection, and gives a reverse-polarity output for lease-line connection. Model FS-MT mounts within the FS-250 enclosure. Model FS-MT parameters are programmed at the time of system configuration.

Auxiliary Devices

Model FS-250 panel supports up to four (4) remote LCD displays and eight (8) serial annunciators or serial relay units.

Remote LCD Annunciator (FS-RD2)

Model FS-250 supports a remote LCD display — Model FS-RD2, which uses the same 80-character, backlit LCD display found on the main FS-250 fire alarm control panel. Model FS-RD2 has remote *Acknowledge*, *Alarm Silence*, and *System Reset* capability that is secured with a keyswitch. User-level functions are accessible from Model FS-RD2.

Model FS-RD2 communicates with Model FS-250's main system board, via a RS-485 communication network. Up to four (4) Model FS-RD2 remote displays can be supported on a single FS-250 fire alarm control panel. Model FS-RD2 mounts in a 2"-deep, 6-gang electrical box, and the plate on the display is suitable for flush mounting.

Programmable Remote Relays (FS-RU2)

Programmable relays are available on the Model FS-250 control panel. A remote processor board (Model FS-RU2) communicates with the main system board, via a RS-485 communication network. Model FS-RU2 processor board controls a relay board mounted adjacent to it.

Specifications — (continued)

The relay board has eight (8) Form C relay contacts – rated at 1 amp at 28VDC maximum. Model FS-RU2 relay unit contains one (1) processor board and one (1) relay board, totaling eight (8) relays.

Each processor board can support up to three (3) relay boards simultaneously, totaling 24 programmable relays per processor board. Additional relay extender boards are available, Model FS-RE8. A total of eight (8) processor boards can be supported simultaneously by each FS-250 control panel.

Programmable Serial Annunciator Drivers (FS-SAU2)

Programmable serial annunciator drivers are available on the Model FS-250 control panel. A remote processor board communicates with the main system board, via a RS-485 communication network. This processor board controls a serial-annunciator driver board mounted adjacent to the remote processor board. The driver board has 16 outputs for LEDs. All serial-annunciator outputs are supervised.

Model FS-SAU2 serial-annunciator unit contains one (1) processor board and one (1) serial-annunciator driver board to add 16 LED drivers. Each processor board can support up to four (4) additional driver boards simultaneously, totaling 64 programmable serial-annunciator drivers per processor board.

Additional serial annunciator extender boards are available as Model FS-SAE16. A total of eight (8) processor boards can be supported simultaneously by each Model FS-250 control panel.

Programming / Configuration Options


Configuration of the FS-250 control panel can be accomplished in two ways: First, the operator interface includes a 16-button keypad. This keypad can be used to configure all system parameters – including custom messages and logic – directly at the panel with no other configuration tools. Secondly, the Model FS-CT2 configuration tool can be used on a laptop computer to upload, download, and edit the system configuration.

Model FS-CT2 configuration tool includes a connection cable for use between the FS-250 fire alarm control panel and a 9-pin serial connection on a laptop computer running Model FS-CT2 software. Use of Model FS-CT2 software requires a computer that runs on a Windows®-based PC operating system. Model FS-CT2 configuration tool can be used to generate configuration reports and download and print history.

Custom messages for system addresses consist of two (2) lines – 20 characters per line. The characters include upper and lower case letters as well as numbers, punctuation marks, and control characters. This 40-character custom message will be displayed for all events at that address.

Technical Data

Environmental:	Operating Temperature: 32-120°F (0-49°C) Relative Humidity: up to 93% @ 90°F (32°C)
Primary Power Supply:	Primary Input Voltage: 120 VAC (60 Hz.) Maximum Primary Input Current: 2.4 Amps. @ 120 VAC
Secondary Power Supply:	24-volt, lead-acid battery with 7AH - 38AH capacity
Auxiliary Power Outputs:	Current - 0.5 Amp with resettable and non-resettable power outputs
System Status Relays:	Four (4) relays rated @ 1 Amp, 28 VDC resistive
Notification Appliance Circuits:	Rating per NAC circuit, 1.5A each, 6A max.
Battery:	Base cabinet accommodates a 12 AH battery set. Larger batteries require separate enclosures.



(Front View)

(Shown In Inches)


Details for Ordering

Model Number	Part Number	Description
FS-250-EKIT	599-050586	FS-250 Electronics Package Includes: FS-250-CON (1 Qty.) FS-NPE (2 Qty.)
FS-250-ENCL	500-648952	FS-250 Enclosure, Black
FS-250-ENCL-R	500-648953	FS-250 Enclosure, Red

Optional Accessories

Model Number	Part Number	Description
FS-RD2-R	500-649400	Remote Annunciator, Red
FS-RD2	500-648980	Remote Annunciator, Black
FS-RU2	500-649308	Relay Processor Card
FS-RE8	500-699467	8-Relay Extender
FS-SAU2	500-649307	Serial Annunciator Processor Card
FS-SAE16	500-699469	16-Output Annunciator Extender
FS-DACT	500-699464	Serial Digital Alarm Comm. Transmitter (DACT)
FS-MT	500-699462	Municipal Tie Module
FS-SFT-R	500-648955	Semi-Flush Trim, Red
FS-SFT	500-648954	Semi-Flush Trim, Black
FS-NPE	500-649120	NAC Power Expander Transformer
HFPO-11	500-034800	Photo-Only Detector

Wiring Diagram Main Termination Board





Notice: This marketing catalog sheet is not intended to be used for system design or installation purposes. For the most up-to-date information, refer to each product's installation instructions.

FS-DACT

Digital Alarm Communication Transmitter for the FireSeeker FS-250 System

ENGINEER AND ARCHITECT SPECIFICATIONS

-  UL Listed for Central Station/Remote Station Monitoring (NFPA 72 Chapter 4)
- Four separate monitoring accounts available
- Two phone lines available
- Can send serial information to monitoring station
- Reports in 8 standard communication formats
- Automatic 24 hour test available
- Mounts within the FS-250 enclosure directly on the main processor board
- All programming is done as part of the FS-250 configuration



The Model FS-DACT Digital Alarm Communication Transmitter is used to provide communication between the FS-250 and a central or remote monitoring station. The FS-DACT supports two lines and four accounts, and can transmit serial information (including the address of the event) to the monitoring station. Any of the accounts can send alarm, supervisory, trouble, reset, or trouble restore information (or any combination) as required. Communication protocols available include SIA DCS 8, SIA DCS 20, Ademco Contact ID, 3/1 1400 Hz, 3/1 2300 Hz, 4/2 1400 Hz and 4/2 2300 Hz. The FS-DACT can perform the automatic 24 hour test required by NFPA.

The FS-DACT mounts within the FS-250 enclosure on an 8-pin connection point on the main board. No external enclosure is required, and no wires are required between the panel and the dialer. Programming of account and dialing information is done as part of the system configuration. No external programmer for the dialer is required, and dialer information can be downloaded as part of the system configuration.

Ordering Information

Model Number	Description	Part Number
FS-DACT	Digital dialer for the FS-250	500-699464

NOTICE: The use of other than Fire Safety detectors and bases with Fire Safety equipment will be considered a misapplication of Fire Safety equipment and as such voids all warranties either expressed or implied in regard to loss, damage, liabilities and/or service problems.

Siemens Building Technologies
Fire Safety

Fire Safety
8 Fernwood Road
Florham Park, NJ 07932
Tel: (973) 593-2600
FAX: (973) 593-6670
Website: www.sbt.siemens.com/fis

1/04
5M
SFS-IG
Printed in U.S.A.


Fire Safety
2 Kenview Boulevard
Brampton, Ontario
Canada L6T 5E4
Tel: (905) 799-9937
FAX: (905) 799-9858

January 2004
Supersedes sheet dated 6/03

FS-RD2

Remote LCD Annunciator for the FireSeeker FS-250 System

ENGINEER AND ARCHITECT SPECIFICATIONS

- 4 x 20 Character Backlit Display
- System Status LEDs
- Optional local sounder
- Built-in lamp test button
- Integral System Control Capabilities (with keyswitch)
- Integral System Maintenance access (with keyswitch and password)
-  UL Listed



The Model FS-RD2 Remote Display is used for annunciating system events remotely from the fire alarm control panel on the FireSeeker FS-250 system. The FS-RD2 will mimic the system status LEDs and the 80-character event message found on the main system panel. The 4 x 20 LCD backlit display will illuminate upon receiving any event from the system, or upon pressing any button on the FS-RD2.

System Acknowledge, Silence and Reset Capabilities are available on the FS-RD2. The control functions must be enabled using the integral keyswitch. Up to sixteen supervised FS-RD2 annunciators can be used simultaneously on the FireSeeker FS-250 system.

Mounting is accomplished using a standard 6 gang 2" deep electrical box. The FS-RD2 requires a 2-wire data connection from the RS-485 port on the FS-250, as well as 24VDC power. Maximum wire loop resistance is 25 ohms.

Ordering Information

Model Number	Description	Part Number
FS-RD2	Remote LCD display for the FS-250	500-648980

NOTICE: The use of other than Fire Safety detectors and bases with Fire Safety equipment will be considered a misapplication of Fire Safety equipment and as such voids all warranties either expressed or implied in regard to loss, damage, liabilities and/or service problems.

Siemens Building Technologies
Fire Safety

Fire Safety
8 Fernwood Road
Florham Park, NJ 07932
Tel: (973) 593-2600
FAX: (973) 593-6670
Website: www.sbt.siemens.com/fis

1/04
5M
SFS-IG
Printed in U.S.A.

Fire Safety
2 Kenview Boulevard
Brampton, Ontario
Canada L6T 5E4
Tel: (905) 799-9937
FAX: (905) 799-9858



January 2004
Supersedes sheet dated 6/03

FireFinder XLS & FS-250 Control Panels

Addressable *FirePrint*[™] Detector

Model HFP-11

ARCHITECT AND ENGINEER SPECIFICATIONS



- Most sophisticated 'detector intelligence' available
- Multi-criteria fire detection for the price of a photoelectric detector
- *FirePrint*[™] technology to differentiate between deceptive phenomena and an actual fire
- Easily programmed to match specific hazard profiles from the control panel
- Polarity insensitive utilizing *SureWire*[™] technology
- Pre-alarm reporting based on fire profile selected
- Remote sensitivity-measurement capability
- System logic activation based on any of three (3) inputs from the detector (smoke, heat or neural network)
- Detectors are self-testing:
 - complete diagnostics every four (4) seconds
- Two-wire operation
- Multi-color detector status LED
- Field-cleanable chamber with replaceable chamber parts available
- Compatible with Model DPU (device programmer / tester unit)
- Supports software-based automatic environmental compensation
- Optional fully programmable relay base, audible base and duct housing
- UL and ULC Listed;
FM, CSFM & NYMEA Approved



Product Overview

Model HFP-11 utilizes advanced detection technology that allows the detector to distinguish non-threatening deceptive phenomena — such as cigarette smoke, from actual fire hazards, while optimizing detection for the area it is intended to detect. Model HFP-11 uses state-of-the-art microprocessor circuitry with error check, detector self-diagnostics and supervision programs.

Model HFP-11 is compatible with the Siemens — Fire Safety field device program / test unit (Model DPU), which is a compact, portable, menu-driven accessory for electronically programming and testing detectors, easily and reliably. Model DPU eliminates the need for cumbersome, unreliable mechanical programming methods — such as dials or switches, and reduces installation and service costs by electronically programming and testing the detector prior to installation. Model HFP-11 is compatible with FS-250 and Fire Finder XLS-series control panels.

Model HFP-11 is Underwriters' Laboratory and Underwriters' Laboratory of Canada listed.

Specifications

Model HFP-11 is a plug-in, two-wire and multi-sensor detector (with both photoelectric and thermal inputs) that is compatible with Fire Finder XLS and FS-250 series of control-panel systems. Each detector consists of a dust-resistant, field-cleanable and photoelectric chamber; a solid state, non-mechanical thermal sensor, and microprocessor-based electronics with a low-profile plastic housing. Model HFP-11 utilizes state-of-the-art ASIC circuitry and surface-mount technology for maximum reliability.

Every Model HFP-11 fire detector is shipped with a protective dust cover. Model HFP-11 utilizes an infrared light emitting diode (IRLED), and light-sensing photodiode. Under normal conditions, light transmitted by the LED is directed away from the photodiode and scattered through the smoke chamber in a controlled pattern.

FS-250 and FireFinder XLS Control Panels **6301**

Specifications – (continued)

The smoke chamber is designed to manage light dissipation and extraneous reflections from dust particles or other non-smoke, airborne contaminants in such a way as to maintain stable, consistent detector operation. When smoke enters the detector chamber, light emitted from the IRLLED is scattered by the smoke particles, and is received by the photodiode.

Model HFP-11 also utilizes a modern, accurate and shock-resistant thermistor to sense temperature changes. The 'on-board' *FirePrint*[™] technology allows the detector to first gather smoke and thermal data, and then analyze this information in the detector's 'neural network.' By comparing data received with the common characteristics of fires or fire fingerprints, Model HFP-11 can compare these 'fire prints' to those of deceptive phenomena that cause other detectors to false alarm.

FirePrint

The advanced *FirePrint* technology allows Model HFP-11 to accurately determine a true fire hazard from unthreatening, deceptive phenomena. Further, the advanced *FirePrint* technology will not require a need to use alarm-delaying verification and confirmation techniques, which can increase the probability of losses due to fire. Model HFP-11 provides the highest level of detector intelligence available today with a detector / control panel link that allows the user to program the detector for the specific hazard profile, using a simple software menu selection.

Model HFP-11's *FirePrint* application monitors input from both the photo chamber and the thermal sensor, evaluating this information with sophisticated mathematical formulas or algorithms, comparing this input to characteristics of both threatening fires and deceptive phenomena that would mislead any ordinary detector.

Detectors are optimized by selecting one (1) of the following 11 applications:

- Office / Retail
- Lobby
- Computer room
- Dormitory
- Healthcare
- Parking garage
- Utility / Transformer room
- Hostile environment
- Precious storage
- Air Duct
- Warehouse / Light Manufacturing

The control panel programs Model HFP-11 detector for the protected area without hassle and without confirmation delays. Once optimized for the hazards in the protected area, Model HFP-11 provides the best detection. Should the operator or installer forget to program the detector, Model HFP-11 will revert to a default setting, allowing operation as an office-environment detector.

The *FirePrint* technology was developed over years of research and reviewing the results of over 20 years of fire test data in one of the world's most advanced fire-research centers.

The results of this research are the mathematical models that form the algorithms used in *FirePrint*. No other fire detector has this level of intelligence or this amount of research and development supporting its design. The microprocessor's software can identify and disregard false input caused by radio frequency (RFI) and electromagnetic (EMI) interference, while validating all *Trouble* conditions before annunciating or reporting to the control panel.

Model HFP-11

The Model HFP-11 detector's microprocessor uses an integral EEPROM to store the detector's address and other critical operating parameters, which include the assigned program values for *Alarm* and *Trouble* thresholds.

Communication within the detector, as well as between Model HFP-11 and the control panel, or with Model DPU (field device programmer / test unit), are supervised and safe-guarded against disruption by reliable, microprocessor-based error checking routines.

Additionally, the micro-processor supervises all EEPROM memory locations, and provides a high degree of EEPROM-failure fault tolerance. Model HFP-11 determines its operating status to be *Normal* in *Alarm* or in *Trouble* modes, depending on the difference between the alarm threshold values stored in the detector's memory and the detector's latest analog measurement.

The detector then communicates changes in its status to the control panel. In addition, the FireFinder XLS control panel will sample the value of the analog signal for Model HFP-11 over a period of time, in order to determine if those values indicate excessive buildup in the photo chamber. If such is the case, the FireFinder XLS control panel will indicate the particular detector requires maintenance.

Model HFP-11 is listed as a self-testing device. The visible light emitting diode (LED) for Model HFP-11 flashes 'green' every four (4) seconds to indicate it is communicating with the control panel, as well as to indicate it has passed its internal self-test. Should the detector sense a fault or failure within its systems, the LED will flash 'amber,' and the detector will transmit that data to the control panel.

A quick visual inspection is enough to indicate the condition of the detector at any time. If more detailed information is required, a printed report can be provided from the Fire Finder XLS panel, indicating the status and settings assigned to each individual detector. When Model HFP-11 moves to the *Alarm* mode, it will flash 'red,' and will continue flashing until the system is reset at the control panel. Simultaneously, any user-defined, system-alarm functions programmed into the system are activated.

Specifications – (continued)

Detector sensitivity, calibration and identification are dynamically supervised by the fire-alarm control panel (FACP). Detector sensitivity and pre-alarm levels are a function of the application chosen at the control panel, and are controlled by the panel. If an alternate, non-*FirePrint* mode is selected, then the sensitivity can be changed from the control panel.

All Model HFP-11 detectors use a surface mounting base, Model DB-11, which mounts on a 4-inch octagonal, square or single gang electrical box. The base utilizes screw-clamp contacts for electrical connections and self-wiping contacts for increased reliability. Model DB-11 can be used with the optional Model LK-11 detector locking kit, which contains 50 detector locks and an installation tool to prevent unauthorized removal of the detector head. Model DB-11 has integral decorative plugs to cover the outer mounting screw holes.

Model HFP-11 may be installed on the same initiating circuit with HMS series manual stations, HTRI series interfaces, HCP output control devices, or HZM series of addressable, conventional zone modules. All Model HFP-11 detectors can be cleaned in the field, when required, by simply removing the detector cover and unsnapping the photo chamber. There is also the option of cleaning the interior of the detector with a clean, soft cloth or brush, or by replacing the labyrinth and bug screen included in the detector maintenance kit, Model DMK-11.

All Model HFP-11 detectors are approved for operation within the UL-specified temperature range of 32 to 100°F (0 to 38°C).

Model DPU

The Device Program / Test Unit accessory is used to program and verify the address of the detector. The technician selects the accessory's program mode, and enters the desired address. Model DPU automatically sets and verifies the address and tests the detector.

Model DPU operates on AC power or rechargeable batteries, providing flexibility and convenience in programming and testing equipment from practically any location.

When in the test mode, Model DPU will perform a series of diagnostic tests without altering the address or other stored data, allowing technicians to determine if the detector is operating properly.

Application Data


Installation of the Model HFP-11 series of fire detectors requires a two-wire circuit. In many retrofit cases, existing wiring may be used. 'T-tapping' is permitted only for Style 4 (Class B) wiring. Model HFP-11 is polarity insensitive, which can greatly reduce installation and debugging time. Model HFP-11 fire detectors can be applied within the maximum 30 foot center spacing (900 sq. ft. areas,) as referenced in NFPA 72. This application guideline is based on ideal conditions, specifically, smooth ceiling surfaces, minimal air movement, and no physical obstructions between potential fire sources and the actual detector. Do not mount detectors in close proximity to ventilation or heating and air conditioning outlets. Exposed joints or beamed ceilings may also affect safe spacing limitations for detectors.

Should questions arise regarding detector placement, observe NFPA 72 guidelines. Good fire-protection system engineering and common sense dictate how and when fire detectors are installed and used. Contact your local Siemens Industry – Fire Safety distributor or sales office whenever you need assistance applying *FirePrint* in unusual applications. Be sure to follow NFPA guidelines and UL Listed / UL Listed installation instructions – included with every Siemens – Fire Safety detector – and local codes as for all fire protection equipment.

Technical Data

Operating Temperatures:	+32°F (0°C) to 100°F (38°C), per UL 268 / 268A
Humidity:	0-93% Relative Humidity
Non-condensing Maximum Spacing:	30-foot Centers (900 Square Feet), per NFPA 72 Chapter 5 and UL-S524

Mounting Diagram



Details for Ordering

Model Number	Part Number	Description
HFP-11	500-033290	Addressable <i>FirePrint</i> [™] Fire Detector
DB-11	500-094151	Detector Mounting Base for Series 11
DB-11E	500-094151E	Detector Base {small}
AD2-P	500-649706	Air-Duct Housing
AD2-XHR	500-649708	Air-Duct Housing {with relay}
DB-HR	500-033220	Relay Base for H-Series Intelligent Detectors
ADBH-11	500-033210	Audible Base
RL-HC	500-033230	Remote Alarm Indicator: 4" octagon-box mount, red
RL-HW	500-033310	Remote Alarm Indicator: single-gang box mount, red
LK-11	500-695350	Base Locking Kit for Series 11 Detectors
DMK-11	500-695338	Series 11 Maintenance Kit {replacement labyrinth and bug screen}

In Canada, order:



Model Number	Part Number	Description
DB-11C	500-095687	Detector Mounting Base for Series 11 Detectors (cULC)

Notice: This marketing catalog sheet is not intended to be used for system design or installation purposes. For the most up-to-date information, refer to each product's installation instructions.

FireFinder XLS & FS-250 Control Panels

Intelligent Thermal Detector Model HFPT-11

ARCHITECT AND ENGINEER SPECIFICATIONS

- Microprocessor-based design
- Rate compensated
- Innovative technology provides high-speed, fault-tolerant system / detector communications
- Multi-color detector status LED
- Polarity insensitive utilizing *SureWire*[™] technology
- Detectors are self-testing:
Complete diagnostics every four seconds
- Two-wire operation
- Compatible with DPU device programmer / tester unit
- UL and ULC Listed;
FM, CSFM & NYMEA Approved





Product Overview

Model HFPT-11 Intelligent Thermal Detector provides an advanced method of detection, address programming and supervision – combined with sophisticated control-panel communication. Model HFPT-11 uses a state-of-the-art thermistor that provides up to 135°F (57.2°C) rate-compensated temperature.

The Intelligent Thermal Detector is compatible with the Device Program / Test Unit (Model DPU). Model DPU is a compact, portable and menu-driven accessory that makes programming and testing detectors faster, easier and more reliable than other methods.

Model DPU eliminates the need for cumbersome, unreliable mechanical-programming methods, and reduces installation and service costs, via electronically programming addresses and functionally testing the HFPT-11's performance before the detector is installed.

The HFPT-11 thermal detector is Underwriters' Laboratory and Underwriters' Laboratory of Canada listed.

Specifications

Model HFPT-11 is a plug-in, (2) two-wire thermal detector, compatible with the FireFinder XLS and FS-250 families of control panels. Each Model HFPT-11 detector has microcomputer-chip technology and highly stable, solid-state electronic circuitry.

Model HFPT-11 detectors utilize a modern, accurate and shock-resistant thermistor to sense temperature changes. This electronic-sensing method virtually eliminates thermal lag associated with mechanical temperature-sensing devices, and provides almost instantaneous temperature information to the control panel. Model HFPT-11, in its default mode, provides up to 135°F (57.2°C) rate-compensated temperature.

FireFinder XLS and FS-250 Control Panels **6302**

Specifications – (continued)

Model HFPT-11 can be programmed from the control panel as a fixed temperature detector without rate-of-rise, at the user's option.

Model HFPT-11 detector's microprocessor uses an integral EEPROM to store the detector's address. Communications within the detector itself and between the HFPT-11 and the control panel, or with Model DPU, are supervised and safeguarded against disruption by reliable, microprocessor based error checking routines. Additionally, the microprocessor supervises all EEPROM memory locations, and provides a high degree of EEPROM failure-fault tolerance.

Model HFPT-11 is listed as a self-testing device. Model HFPT-11's visible light emitting diode (LED) flashes green every four (4) seconds to indicate it is communicating with the control panel, and to show it has passed its internal self-test. Should the detector sense a fault or failure within its systems, the LED will flash amber, and the detector will transmit that information to the control panel.

A quick visual inspection is sufficient to indicate the condition of the detector at any time. If more detailed information is required, a printed report can be provided from the FireFinder XLS panel indicating the status and settings assigned to each individual detector.

When Model HFPT-11 moves to the *alarm* mode, it will flash red and continue flashing until the control panel is reset. At that same time, any user-defined system alarm functions programmed into the system are activated.

A Device Program / Test Unit (Model DPU) is used to program and verify the detector's address. The user selects the program mode to enter the desired address. The DPU Programmer / Test Unit then automatically sets / verifies the address, as well as tests the detector.

Model DPU has rechargeable batteries, which allows a detector's address to be programmed by the user from the most convenient location. The user can also separately test the detector for functionality.

When the user selects the *test* mode, a series of tests are automatically conducted and the user is informed whether the detector has passed or failed.

Model HFPT-11 detector is compatible on the same FireFinder XLS or FS-250 initiating circuit with other H-series detectors, HMS manual stations, HTRI-series addressable interfaces, or HZM-series addressable, conventional zone modules.

Model HFPT-11 detectors use a surface mounting base, (Model DB-11), which mounts on a 4-inch octagonal, square or single gang electrical box. Relay base Model DB-HR mounts to a 4-inch-square-deep electrical box.

Audible base Model ADBH-11 also mounts to a 4-inch-square-deep electrical box. Model DB-11 as well as Models DB-HR and ADBH-11 use screw-clamp terminals for all electrical connections and self-wiping contacts for reliability. The bases also contain a provision for an optional, concealed locking mechanism to prevent unauthorized removal of the detector head, Model LK-11.

Application Data


The FireFinder XLS and FS-250 control panels use loop circuits with each circuit capable of supporting up to 252 Model HFPT-11 intelligent detectors.

Locate Model HFPT-11 on the ceiling, at least 4 inches from the side walls. For an ideal, smooth ceiling condition, place the detectors at a maximum center spacing of 50 feet (2,500 square feet), 25 feet from side walls or room partitions. For FM-approved installations, Model HFPT-11 has a RTI rating of 'FAST.' Use a maximum center spacing of 25 feet (625 square feet), 12.5 feet from side walls or room partitions.

Actual job conditions and sound engineering judgment must determine detector spacing. Consider environmental factors including ambient temperature fluctuation, and the nature of the fire hazard. Room or area configuration and ceiling type (sloped or flat, smooth or beamed) also dictates placement.

Should questions arise regarding detector placement, follow the drawings provided and / or approved by Siemens Industry – Fire Safety Division or by its authorized distributors.

Mounting Diagram



Technical Data

Operating Temperatures:	+32°F (0°C) to 100°F (38°C), per [®] UL 269 / 268A
Humidity:	0-93% Relative Humidity Non-condensing
Maximum Spacing:	50-foot Centers (2500 Square Feet)
FM-Approved Spacing:	25-foot Centers (625 Square Feet)
Current Draw:	1mA in <i>Alarm</i> or <i>Supervisory</i> mode

Details for Ordering

Model Number	Part Number	Description
HFPT-11	500-033380	Addressable Thermal Fire Detector
DB-11	500-094151	Detector Mounting Base
DB-HR	500-033220	Relay Base
ADBH-11	500-033210	Audible Base
RL-HC	500-033230	Remote (red) alarm indicator-octogan box mount
RL-HW	500-033310	Remote (red) alarm indicator-single gang box mount
LK-11	500-695350	Base Locking Kit for Series 11 detectors

In Canada Order:

Model Number	Part Number	Description
ADBH-11C	500-033210C	Audible Base (ULC)
HFPT-11C	500-033380C	Addressable Thermal Fire Detector (ULC)
DB-11C	500-095687	Detector Mounting Base (ULC)
DB-HR-C	500-033220C	Relay Base (ULC)

This Page Left Intentionally Blank

Notice: This marketing catalog sheet is not intended to be used for system design or installation purposes.
For the most up-to-date information, refer to each product's installation instructions.

SIEMENS Industry, Inc.
Building Technologies Division

Fire Safety
8 Fernwood Road
Florham Park, NJ 07932
Tel: (973) 593-2600
FAX: (908) 547-6877
URL: www.SBT.Siemens.com/FIS

SII
Printed in U.S.A.

Fire Safety
2 Kenview Boulevard
Brampton, Ontario
L6T 5E4 / Canada
Tel: (905) 799-9937
FAX: (905) 799-9858

June 2010
Supersedes sheet dated 7/09
(Rev. 2)

Installation/Wiring Instructions MODEL DB-11/-11E DETECTOR BASE




Figure 1 Wiring Diagram for DB-11/-11E using PE-11, PE-11T, and DT-11 Detectors




Figure 2 Wiring Diagram for DB-11/-11E using FP-11, FPT-11, FS-DP, FS-DPT, and FS-DT Detectors




Figure 3 Wiring Diagram for DB-11/-11E using HFP-11 Series and SFP-11 Series Detectors

Siemens Building Technologies, Inc.
8 Fernwood Road
Florham Park, New Jersey 07932

Siemens Building Technologies, Ltd.
2 Kenview Boulevard
Brampton, Ontario, Canada L6T 5E4

Model DB-11/-11E
(P/N 500-094151/500-094151E)

DETECTOR AND BASE PLACEMENT

Detector and base locations shall follow the drawings provided or approved by Siemens Building Technologies, Inc. or its authorized distributors. This is extremely important! The detector placements shown on these drawings were chosen after a careful evaluation of all facets of the protected area. When drawings are not available, refer to *Detector Placement* section of detector Installation/Wiring Instructions and to NFPA Standard 72 and CAN/ULC-S524.

BASE WIRING

Siemens Building Technologies, Inc.'s detectors should be interconnected as shown in Figures 1, 2 or 3 and wired to the control panel following the wiring connection drawing installed on the inside face of each control panel cover. NOTE: H Series devices are wired to the DLC or FS-DLC; S Series devices are wired to the FDLC. **Note any limitations on the number of detectors and restrictions on the use of remote devices permitted for each circuit.**

DETECTOR MOUNTING USING THE DB-11/-11E BASE

The detector is provided with a separate base which attaches to a standard 4 inch square, 4 inch octagonal, or single gang electrical box, with the box size and depth required by the NEC for the number and size of conductors used. Wire size: max – 14 AWG, min – 18 AWG.

Refer to Figures 4 and 5, as applicable.

1. Route all wires outward from outlet box.
2. When ALARM LED viewing is critical, position the LED mark in the base in the intended direction.
3. Route wires through the hole in the center of the base and mount base to outlet box. Make connections directly to the base terminals. Refer to Figures 1, 2 and 3 for details.
4. After all bases are installed, check loop continuity. Refer to the System Manual for the loop continuity check procedure. To allow for the continuity check with PE-11, PE-11T or DT-11 detectors, use DBJ-11 Jumper Kit, P/N 500-699167 (between terminals 1a and 1b) to complete the loop. Do not use a jumper for FP-11/HFP-11/FS/SFP-11 family devices.
5. Continuity jumper must be removed from each base prior to installing detector.
6. To insure proper installation of the detector head into the base:
 - a. Route wires away from connector terminals.
 - b. Take up all slack in the outlet box.
 - c. Properly dress and position all wires flat against the base.
 - d. Check that screw terminals are tight.
7. (DB-11 only) Break off the two mounting hole covers, and insert in two outer base mounting holes.




Figure 4
Mounting The DB-11 Base





Figure 5
Mounting The DB-11E Base

Conventional Fire Detectors

Thermal Fire Detectors

Models DT-135R, DT-135F, DT-200R and DT-200F

ARCHITECT AND ENGINEER SPECIFICATIONS

-  Listed
- FM Approved



Product Overview

The Siemens Building Technologies — Fire Safety Division Thermal Fire Detectors are fixed temperature or a combination of fixed-temperature / rate-of-rise type. The combination detectors consist of two, independently operated thermal elements. The rate-of-rise element is self-restoring. However, the fixed temperature is of the non-restoring type.

Underwriter's Laboratories, Inc., recommends the combination-type thermal detector be used to protect a maximum of 2,500 square feet (50-foot spacing), and the fixed-temperature type be used to protect a maximum of 625 square feet (25-foot spacing). However, job conditions and engineering judgment often dictate closer spacing to provide faster detection.

The thermal fire detector shall be Fire Safety Model ____ (insert number), and shall operate at a temperature of ____°F (insert temperature). The detectors shall be listed by Underwriters' Laboratories, Inc. and Factory Mutual for use with Siemens Building Technologies, — Fire Safety Division systems.

Specifications

Rate-of-Rise Principle of Operation

The rate-of-rise element consists of an air chamber; a flexible, metal diaphragm and a moisture-proof, trouble-free vent that is carefully calibrated.

It is well known air expands as it is heated, and will contract as it is cooled. For normal, day-to-day fluctuations of temperature, the expansion and contraction of the air within the chamber is automatically compensated by the 'breathing' action of the vent.

However, when a fire occurs, air temperatures rise very rapidly and the air in the chamber expands faster than it can be vented. This creates a pressure which distends the diaphragm and closes electrical contacts.

The rate-of-rise action is not related to any fixed temperature level, but responds with the utmost promptness when the rate of temperature rise exceeds 15°F per minute. If the heat is removed, the air within the chamber contracts and the switch moves to a normally open circuit position.

DT-series Thermal Fire Detectors **6130**

Specifications — (continued)

Fixed Temperature Principle of Operation

In a slow-developing fire, the temperature may not increase rapidly enough to operate a rate-of-rise element. Therefore, a fixed-temperature principle of operation is needed.

The detector utilizes a fixed-temperature element made of fusible alloy and is of the non-restorable type.

The fusible alloy will melt and activate the detector when the surrounding air rises above the preset level of 135°F or 194°F.

The external heat collector drops away when the detector is activated therefore giving a quick visual confirmation that the detector has alarmed.





Installation

Each detector includes a thermoplastic, reversible mounting plate. In one position, it easily attaches to a 4" octagon junction box, 3" octagon box or plaster ring.

In reverse, the plate can be used for open wiring without a junction box. A 1/4" space between detector and mounting surface allows for wire connections. All mounting screws are concealed.

The detector simply attaches to the mounting plate with a push-and-twist motion — no tools are required.

Details for Ordering

Model Number	DT-135R	DT-200R	DT-135F	DT-200F
Description	Rate-of-rise and fixed temperature 135°F	Rate-of-rise and fixed temperature 194°F	Fixed temperature only, 135°F	Fixed temperature only, 194°F
Applications	Normal temperature fluctuations and ceiling temperatures not exceeding 100°F	Normal temperature fluctuations and ceiling temperatures exceeding 100°F but not 150°F	Unusually violent temperature fluctuations and ceiling temperatures not exceeding 100°F	Unusually violent temperature fluctuations and ceiling temperatures exceeding 100°F but not 150°F
Identification on Heat Collector				


Notice: This marketing data sheet is not intended to be used for system design or installation purposes. For the most up-to-date information, refer to each product's installation instructions.

SIEMENS MSM SERIES

Fire Safety

Metal Manual Fire Alarm Box

ENGINEER AND ARCHITECT SPECIFICATIONS

- Rugged Die-Cast Metal Housing
- Reset Key Matches Control Panel
- Optional Break Glass Operation
- Single-Gang Semi-Flush Mount
- Optional Surface Mount Backbox
- Double-Action Institutional, Weather-Proof and Explosion-Proof Models Available
-  UL Listed, ULC Listed, CSFM, FM and NYMEA Approved



**Standard Model
Or Weatherproof**



Institutional Model

Description

The MSM Series manual stations feature a rugged die-cast metal housing that satisfies both architectural and code requirements for manual fire alarm box initiation devices. The MSM-Series box features keyed reset using the same key as the control panels.

The MSM Series models are low-profile with all surfaces either painted or plated to inhibit corrosion. These boxes have raised lettering and are shipped with two reset keys and a break glass rod (use of rod is optional.) Options include: double action, institutional, weatherproof, and explosion-proof.

These stations are equipped with a S.P.S.T. switch rated at 10amps @ 120 VAC and all connections are made to a terminal block. The explosion-proof model has a D.P.D.T. switch. **Both the weatherproof and explosion-proof models are shipped complete with backbox.** (Backbox is optional with other models, or you can mount to standard single-gang box.)

These models are intended for use with all Siemens Building Technologies, Fire Safety Division conventional zones, but can also be used with addressable zones when used in conjunction with a TRI-Series addressable module.

Dimensions

Station

Width 3.20 in.
 Height 4.75 in.
 Depth 1.20 in. (2.30 in. overall, including back of switch)

Station w/Double Action

Width 3.33 in.
 Height 4.57 in.
 Depth 1.50 in. (2.60 in. overall, including back of switch)

Weatherproof Model


Width 3.20 in.
 Height 4.75 in.
 Depth 2.75 in.

Explosion-proof Model

Width 3.20 in.
 Height 4.75 in. (6.00 in. overall, including mounting ears)
 Depth 3.50 in.

Ordering Information

Model Number	Description	Part Number
MSM-K	Manual Station, Metal w/Key	500-698215
MSM-KD	Manual Station, Metal w/Key, Double Action	500-698216
MSM-K-WP	Manual Station, Metal w/Key, Weatherproof	500-698217
MSM-KD-WP	Manual Station, Metal w/Key, Weatherproof, Double Action	500-698218
MSM-EXP	Manual Station, Metal w/Key, Explosion-proof	500-698219
MSM-INST	Manual Station, Metal w/Key, Institutional	500-698220
MSM-BOX	Surface Backbox for MSM-series Manual Stations	500-698221



Double Action Model



Explosion-proof Model

Installation Instructions

Model HTRI-M

Addressable Interface Module

The **SIEMENS** Model HTRI-M Series Addressable interface module interfaces direct shorting devices to the DLC loop of the FireFinder-XLS System or the FS-DLC loop of the FS-250 System. It is also approved for 1076, Proprietary Burglary.

The HTRI-M can monitor a normally open or closed dry contact and it can report the status of the contact.




Figure 1
HTRI-M Module

PROGRAMMING

Refer to Figure 1 to locate the red and black DLC/FS-DLC loop circuit wires of the HTRI-M.

Connect the Addressable Loop Driver circuit wires of the HTRI-M to the **SIEMENS** Model DPU Programmer/Tester. Use the cable provided with the Programmer/Tester and the 2 alligator clip to banana plug adapters provided.



To Prevent Damage To The DPU:

DO NOT connect a HTRI-M to the DPU until all field wiring is removed from the red and black DLC/FS-DLC loop circuit wires of the HTRI-M.



Connection from the DPU to the HTRI-M is not polarity sensitive. Refer to Figure 3 for the proper connections to the control panel.

(Refer to Figure 2.) Follow the instructions in the **DPU Programmer/Tester Manual** (P/N 315-033260) to program the desired address into HTRI-M.

Record the device address on the label located on the HTRI-M. The HTRI-M can now be installed and wired to the system.



NOTES:

1. There can be any number of normally closed or normally open switches.
2. The end of line resistor must be located at the last switch.
3. Do not wire a normally closed switch across the end of line resistor.
4. Only for use with security and status applications.
5. Do not use N.O. switches for security applications.

Figure 2
Wiring Switches

WIRING

(Refer to Figure 3.) Refer to the wiring diagram and wire the addressable interface module accordingly.



**Recommended wire size: 18 AWG minimum
14 AWG maximum**




Figure 3
Installing the HTRI-M Wiring

NOTES:

1. **All supervised switches must be held closed and/or open for at least a quarter of a second to guarantee detection.**
2. End of line device: 3.6K, 1/4W resistor, P/N 140-820185. For Canadian applications, use Model EL-33 with 3.6K, 1/4W resistor.
3. HTRI-M is polarity insensitive. Line 1 and Line 2 can be either line of the loop.
4. The supervised switches have the following ratings:
 - Voltage maximum: 27 VDC
 - Current maximum: 3.5mA during polling
 - Contact resistance maximum: 10 ohms
 - Maximum cable length: 200 feet (18 AWG)

$C_{\text{Line to line}}$: 0.02uF
Max line size: 14 AWG

$C_{\text{Line to shield}}$: 0.04uF
Min line size: 18 AWG



Ground shield ONLY at the specified location on the Control Panel.

5. The green wire must be connected to earth ground.
 - a. Use wire nuts to pass the shield wire through the electrical box with **NO** connection to the device green wire.
 - b. Use shielded wire to connect the switch wiring.
 - c. Tie the switch wiring shield to earth ground.
6. For proprietary burglary application:
 - a. Use a TSW-1/2 tamper switch to monitor the main enclosure.
 - b. Monitor each HTRI-M related to this application continuously by using a listed motion detector (to prevent tampering).
7. In supervisory: HTRI-M draws 1.5mA
8. All circuits are power limited.

MOUNTING

The SIEMENS Model HTRI-M mounts directly into a single gang switchbox (user supplied)

Connect the appropriate wires using wire nuts. Tuck the HTRI-M module inside the electrical box and dress the wiring as required. (See Figure 4.)




Figure 4
Mounting the HTRI-M

FireFinder XLS and FS-250 Panels

HTRI Series Interface Modules

Models HTRI-D, HTRI-R and HTRI-S

ARCHITECT AND ENGINEER SPECIFICATIONS

- Interfacing and supervising normally open (NO) or normally closed (NC) contacts
- Integral SPDT relay on Model HTRI-R (up to 4 amps)
- Dual input on Model HTRI-D, using a single address
- Polarity insensitive with *SureWire™* technology
- Multi-color light-emitting diode (LED) indicates status [green / amber / red]
- Easy front access to programming port and wiring terminals
- Mounts 4-inch square, 2-1/4"-deep box (or double-gang box)
- Dynamic supervision
- Comes with 5-x-5" faceplate
- Two-wire operation
- Model DPU programs and verifies address of the device and tests for proper functionality
- Electronic address programming is easy and dependable
- ©UL Listed & ©ULC Listed;
FM, CSFM and NYMEA Approved



Product Overview

The Siemens Industry, Inc. — Fire Safety HTRI Series Intelligent interface modules are designed to provide the means of interfacing direct shorting devices to the FireFinder XLS and FS-250 Fire Alarm Control Panel loop circuit.

The HTRI Series modules provide the most advanced method of address programming and supervision on the market — combined with sophisticated control panel communication. Each HTRI Series interface module incorporates a microcomputer chip. The HTRI Series microcomputer chip technology and its sophisticated bi-directional communication capabilities with the control panel, achieve the state of an 'intelligent device.'

Specifications

The HTRI Series intelligent interface modules are available in three (3) models. Models HTRI-S and HTRI-R are designed to monitor a (NO) or (NC) dry contact.

The interface module reports the status of the (NO) or (NC) contact to the control panel. Model HTRI-S can only monitor and report the status of the contact, while Model HTRI-R incorporates an addressable Form C relay.

The Model HTRI-R relay and contact device input are controlled at the same address. For the control panel system, the relay and input contact can be controlled as a separate function. The relay is typically used where control or shunting of external equipment is required.

The Model HTRI-D is a dual-input module that is designed to supervise and monitor two (2) sets of dry contacts. Model HTRI-D only requires one (1) address, but responds independently to each input. Model HTRI-D is ideal for monitoring a water-flow switch and its respective valve tamper switch.

Model HTRI has a multi-color LED that flashes 'green' when operating in *normal*; 'amber' if unit is in *trouble* condition, and 'red' to indicate a change of state.

Specifications (continued)

Model HTRI-D flashes twice — once for each address, and Model HTRI-R LED indicates a change of state in the relay. The device's microcomputer chip has the capacity of storing, in memory, identification information; as well as important operating-status information.

Siemens Industry, Inc., — Fire Safety innovative technology allows all HTRI Series intelligent interface modules to be programmed by using the Device Programming / Test Unit. Model DPU is a compact, portable and menu-driven accessory that makes programming and testing an interface device faster, easier and more dependable than previous methods.

Model DPU eliminates the need for mechanical addressing mechanisms, such as: program jumpers, DIP switches or rotary dials, since Model DPU electronically sets the HTRI Series interface address into the interface microcomputer-chip non-volatile memory. Vibration, corrosion and other conditions that deteriorate mechanical addressing mechanisms are no longer a cause for concern.

The HTRI Series is fitted with screw terminals for connection to an addressable circuit. The HTRI Series is fully compatible on the same FireFinder XLS and FS-250 circuits with all intelligent H-Series detectors, HMS Series addressable manual stations, or any other addressable intelligent modules, such as Model HZM or Model HCP.

All HTRI Series intelligent interface modules are ®UL listed. Environmental operating conditions for all HTRI Series modules are 32°F (°C) to 120°F (49°C) with a relative humidity of no greater than 93%, non-condensing.

Electrical Ratings

Current Draw
(Active or Standby) 1mA

Model HTRI-R Relay Ratings


Resistive: 4 Amps, 125 VAC
4 Amps, 30 VDC

Inductive: 3.5A, 120 VAC (0.6P.F.)
3.0A, 30 VDC (0.6P.F.)
2.0A, 120 VAC (0.4P.F.)
2.0A, 120 VAC (0.35P.F.)
2.0A, 30 VDC (0.35P.F.)

Notice: This marketing catalog sheet is not intended to be used for system design or installation purposes. For the most up-to-date information, refer to each product's installation instructions.

Mounting Diagram

Models HTRI-S, HTRI-D and HTRI-R mount directly into a 4-inch square, 2 ¼-inch deep box or a double-gang box (user supplied). A 5-inch square, off-white faceplate is included with each HTRI Series module.



Details for Ordering

Model Number	Part Number	Description	Shipping Wgt.	
			Lb.	Kg.
HTRI-S	500-033370	Single Input	7 oz.	2
HTRI-R	500-033300	Single Input w/Relay	7 oz.	2
HTRI-D	500-033360	Dual Input	7 oz.	2

'08 Series Notification Appliances

ZH & ZR – Strobes, Horns, & Horn / Strobes


Application: Indoor



ZH Series



ZR Series



(ZR & ZH Mounting)

Product Overview

- Strobes can be synchronized using the Siemens DSC sync modules, FS-250 panel, XLS panel, or PAD-3 power supply with built-in sync protocol
- Selectable Continuous Horn or Temporal (Code-3) Tones with 90 or 95 dBA selectable setting (ZH)
- Ceiling-mount models feature field-selectable Candela settings of 15/30/75/95cd and 115/177cd
- Wall-mount models feature field-selectable Candela settings of 15/30/75/110cd and 135/185cd
- Base plate is protected by a disposable cover, and the appliances can quickly snap onto the base after the walls are painted
- Strobes produce 1 flash per second
- "Special Applications" listed with Siemens panels
- EZ Mount Universal Mounting Plate (ZBB) – uses single plate for ceiling and wall mount installations
- EZ Mount design – with separate base plate – provides ability to pre-wire the base and test the circuit wiring before the walls are covered
- UL Listed & ULC Listed;
FM, CSFM & NYMEA Approved
- ADA / NFPA compliant


Specifications

- **General**
 - Audible/Visual notification appliances shall be listed for indoor use only
 - Appliances shall be listed under UL Standard 1971 (Standard for Safety Signaling Devices for Hearing Impaired) and UL Standard 464 (Fire Protective Signaling)
 - Appliances shall use a universal back plate, which shall allow mounting to a single-gang, double-gang, 4-inch-square, 4"-octal, or a 3-1/2"-octal backbox
 - Two-wire appliance wiring shall be capable of directly connecting to the mounting back plate
 - Continuity check shall occur for entire NAC circuit prior to attaching any audible / visual-notification appliances
 - Dust cover shall fit and protect the mounting plate
 - Dust cover shall be easily removed when the appliance is installed over the back plate
 - Removal of an appliance shall result in a trouble condition by the Fire Alarm Control Panel (FACP)

Specifications – (continued)

- **Strobes**
 - Strobe appliances shall produce a minimum flash rate of 60 flashes per minute (1 flash per second) over the Regulated Input Voltage Range, and shall incorporate a Xenon flashtube enclosed in a rugged Lexan® lens
 - Strobes shall be available with two or four field-selectable settings in one unit, and shall be rated – per **UL** 1971 – for up to:
 - 15/30/75/110cd for wall mounted
 - 135/185cd for wall mounted
 - 15/30/75/95cd for ceiling mounted
 - 115/177cd for ceiling mounted
 - Strobes shall operate over an extended temperature range of 32°F to 120°F (0°C to 49°C), and be listed for maximum humidity of 95% RH
 - Strobe inputs shall be polarized for compatibility with standard reverse-polarity supervision of circuit wiring by a Fire Alarm Control Panel (FACP)
- **Audibles and Audible / Strobe Combinations**
 - Horns and horn / strobes shall be listed for Indoor use under **UL** Standard 464
 - Horns shall be able to produce continuous synchronized output or a temporal code-3 synchronized output
 - Horns shall have at least 2 sound-level settings of 90 and 95 dBA
- **Synchronization Modules**
 - The strobe portion, when synchronization is required, shall be compatible with DSC sync modules, FS-250 panel, XLS panel, or PAD-3 power supply with built-in sync protocol
 - The strobes shall not drift out of synchronization at any time during operation
 - Audibles and strobes shall be able to synchronize on a 2-wire circuit with the capability to silence the audible, if required
 - Strobes shall revert to a non-synchronized flash-rate, if the sync module or Power Supply should fail to operate (i.e. – contacts remain closed)
 - All notification appliances shall be listed for Special Applications:
 - Strobes are designed to flash at 1-flash-per-second minimum over their “Regulated Input Voltage Range”
 - **Note:** NFPA-72 specifies a flash rate of 1-to-2 flashes per second, and ADA Guidelines specify a flash rate of 1-to-3 flashes per second
 - All candela ratings represent minimum-effective Strobe intensity, based on **UL** Standard 1971
 - Series ZH Strobe products are listed under **UL** Standards 1971 and 464 for indoor use with a temperature range of 32°F to 120°F (0°C to 49°C) and maximum humidity of 93% (± 2%)
 - Series ZH horns are listed under **UL** Standard 464 for audible signal appliances (Indoor use only)

Mounting Diagram



(Shown In Inches)

Mounting Options




Figure 3: Installation




Figure 4: Removal (See step 8 below)

1. Install mounting plate as shown in figure 1 to a single-gang, double-gang, 4" square, 4" octagon, or a 3 1/2" octagon backbox with the provided pan head screws. To remove dust cover, place thumb and index finger on top edges of cover and pull off cover.
2. Connect field wiring per figures 2 and 3.
3. Address wires back into backbox.
4. Place dust cover over mounting plate to protect the terminals while performing wiring continuity check..
5. Remove dust cover before snapping or installing the appliance onto the mounting plate per fig 3.

6. Important: Device only has one mounting orientation. Match the top of the base to the top of the device.
7. If it is desired to further secure the device to the base, then two optional screws are provided. To install these screws punch out the screw holes located at the top and bottom of the device.
8. To remove the appliance, push a small flat-bladed screwdriver into the side opening. The screwdriver must clear the snap release opening by 1/4" to disengage the snap. Do not pry off housing with the screw driver. Apply pressure with screw driver, inserted in either side opening, as shown in Fig 4 to release the housing.

Technical Data

		ZH and ZH-MC Horn Reverberant dBA per UL464 [ZH-MC and ZH at 24V]		
		16.0V	24V	33.0V
Continuous Horn	High	83	87	90
	Low	77	81	83
Code 3 Horn or March Time*	High	79	82	86
	Low	72	76	79

*Available in sync mode only

In (Amps)	ZH Horn Current Draw	
	Horn Setting	16-33 Volts
DC	High*	0.044
	Low*	0.018
FWR	High*	0.075
	Low*	0.045

*Current Draw is the same for the Continuous Horn, Code 3 Horn and March Time Settings.

Technical Data – (continued)

UL Listed Models and Ratings					
Models*	Operating Voltage (Special Application) [Per UL 1971] (VDC/VRMS)	Voltage Range [Per UL C- S526-02] (VDC/VRMS)	Horn	Mounting	Strobe Candela (cd)
ZR-MC	16.0-33.0	20.0-31.0	—	Wall	15/30/75/110
ZR-HMC	16.0-33.0	20.0-31.0	—	Wall	135/185
ZR-MC-C	16.0-33.0	20.0-31.0	—	Ceiling	15/30/75/95
ZR-HMC-C	16.0-33.0	20.0-31.0	—	Ceiling	115/177
ZH-MC	16.0-33.0	20.0-31.0	X	Wall	15/30/75/110
ZH-HMC	16.0-33.0	20.0-31.0	X	Wall	135/185
ZH-MC-C	16.0-33.0	20.0-31.0	X	Ceiling	15/30/75/95
ZH-HMC-C	16.0-33.0	20.0-31.0	X	Ceiling	115/177
ZH	16.0-33.0	20.0-31.0	X	Wall or Ceiling	— —

*Available in red and white

UL Current Ratings (ZR Strobe Only)													
Maximum RMS Current (AMPS)													
		MC				HMC		MC-C				HMC-C	
		15cd	30cd	75cd	110cd	135cd	185cd	15cd	30cd	75cd	95cd	115cd	177cd
DC	16-33VDC	0.064	0.098	0.175	0.233	0.318	0.445	0.069	0.111	0.200	0.264	0.318	0.445
FWR	16-33VRMS	0.108	0.164	0.268	0.368	0.482	0.684	0.117	0.180	0.297	0.398	0.482	0.684

UL Current Ratings ZH Horn/Strobe														
Maximum RMS Current (AMPS)														
		Horn Setting	MC				HMC		MC-C				HMC-C	
			15cd	30cd	75cd	110cd	135cd	185cd	15cd	30cd	75cd	95cd	115cd	177cd
DC	16-33VDC	High*	0.078	0.113	0.195	0.259	0.371	0.506	0.087	0.131	0.222	0.292	0.371	0.506
		Low*	0.070	0.107	0.188	0.246	0.324	0.455	0.075	0.121	0.213	0.277	0.324	0.455
FWR	16-33VRMS	High*	0.141	0.200	0.302	0.406	0.521	0.722	0.149	0.216	0.331	0.436	0.521	0.722
		Low*	0.123	0.179	0.290	0.391	0.497	0.699	0.131	0.195	0.319	0.421	0.497	0.699

* Current Draw is the same for the Continuous Horn;
Code 3 Horn and March Time Settings

Details for Ordering – (Including Mounting Options & Agency Approvals)

Agency Approvals

Model Number	Part Number	Description	Mounting Options*	UL	ULC	FM	CSFM
ZH-R	500-636159	Z Horn: Red	B,D,E,F	X	X	X	X
ZH-W	500-636160	Z Horn: White	B,D,E,F	X	X	X	X
ZH-MC-R	500-636161	Z Horn: Multi Candela (Wall), Red	B,D,E,F	X	X	X	X
ZH-MC-W	500-636162	Z Horn: Multi Candela (Wall), White	B,D,E,F	X	X	X	X
ZH-HMC-R	500-636163	Z Horn: Hi Multi Candela (Wall), Red	B,D,E,F	X	X	X	X
ZH-HMC-W	500-636164	Z Horn: Hi Multi Candela (Wall), White	B,D,E,F	X	X	X	X
ZH-MC-CR	500-636165	Z Horn: Multi Candela (Ceiling), Red	B,D,E,F	X	X	X	X
ZH-MC-CW	500-636166	Z Horn: Multi Candela (Ceiling), White	B,D,E,F	X	X	X	X
ZH-HMC-CR	500-636167	Z Horn: Hi Multi Candela (Ceiling), Red	B,D,E,F	X	X	X	X
ZH-HMC-CW	500-636168	Z Horn: Hi Multi Candela (Ceiling), White	B,D,E,F	X	X	X	X
ZR-MC-R	500-636169	Z Strobe: Multi Candela (Wall), Red	B,D,E,F	X	X	X	X
ZR-MC-W	500-636170	Z Strobe: Multi Candela (Wall), White	B,D,E,F	X	X	X	X
ZR-HMC-R	500-636171	Z Strobe: Hi Multi-Candela (Wall), Red	B,D,E,F	X	X	X	X
ZR-HMC-W	500-636172	Z Strobe: Hi Multi-Candela (Wall), White	B,D,E,F	X	X	X	X
ZR-MC-CR	500-636173	Z Strobe: Multi Candela (Ceiling), Red	B,D,E,F	X	X	X	X
ZR-MC-CW	500-636174	Z Strobe: Multi Candela (Ceiling), White	B,D,E,F	X	X	X	X
ZR-HMC-CR	500-636175	Z Strobe: Hi Multi Candela (Ceiling), Red	B,D,E,F	X	X	X	X
ZRS-HMC-CW	500-636176	Z Strobe: Hi Multi Candela (Ceiling), White	B,D,E,F	X	X	X	X
ZBB-R	500-636193	Accessory – (Includes base, dust cover, mounting screws and installation sheet)					
ZBB-W	500-636194	Accessory – (Includes base, dust cover, mounting screws and installation sheet)					

X = listed / approved

* = Refer to catalog sheet #: 2585 for detailed mounting options

Notice: This marketing catalog sheet is not intended to be used for system design or installation purposes.
For the most up-to-date information, refer to each product's installation instructions.

NAC Circuit Voltage Drop Calculation

Project Name	Longfellow Commons		
Date	1/25/2013		
Circuit Number	1		
Area Covered	Basement		
NAC Source Alarm Voltage	20.4	Wire Gauge 14	Resistance Per MFt Cable 5.84
Minimum Device Voltage	16		
Distance to first appliance	50		
Total Circuit Current	1.323		

Wire Gauge for balance of circuit	14	5.84
-----------------------------------	----	------

Circuit is within limits					
	Device Current	Distance from previous device	Voltage at Device	Drop from source	Percent Drop
Appliance 1	0.259		20.01	0.39	1.9%
Appliance 2	0.259	50	19.70	0.70	3.4%
Appliance 3	0.078	50	19.47	0.93	4.6%
Appliance 4	0.078	50	19.26	1.14	5.6%
Appliance 5	0.195	50	19.07	1.33	6.5%
Appliance 6	0.078	50	18.93	1.47	7.2%
Appliance 7	0.044	50	18.82	1.58	7.7%
Appliance 8	0.044	50	18.73	1.67	8.2%
Appliance 9	0.078	50	18.64	1.76	8.6%
Appliance 10	0.044	50	18.58	1.82	8.9%
Appliance 11	0.044	50	18.53	1.87	9.2%
Appliance 12	0.044	50	18.50	1.90	9.3%
Appliance 13	0.078	50	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
END	0.000	0	18.47	1.93	9.4%
Totals	1.323	650			

Appliance circuit voltage drop calculations start at "end of battery life" as NAC Source Alarm Voltage and use 20% below nameplate rating for Minimum Appliance Voltage.

Note. Wire resistance is based on the 1996 NEC Table 8 Uncoated DC resistance. Solid conductors except gauges 10 and 12 which are for stranded.

Siemens FACP Battery Calculations

Job Name: Longfellow Commons


Date: 1/ 3/13

TOTAL SYSTEM CURRENT	STANDBY	ALARM
	0.553	2.552


TOTAL FACP BATTERY CALCULATIONS			
TOTAL STANDBY CURRENT	A/H REQ'D		A/H STANDBY
0.553 Amps X	24	HRS.	13.267
TOTAL ALARM CURRENT	A/H REQ'D		A/H ALARM
2.552 Amps X	5	MIN.	0.266


Required Battery Capacity	13.533
Always use a battery with higher AH rating than required.	

BATTERY SUPPLIED: 2x18 AH



FIRE ALARM SYSTEM LAYOUT - GROUND FLOOR


GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME CONTRACT WITH: WESTON ASSOCIATES MGMT.  EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210	FIRE ALARM SYSTEM
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72			OWNER PORTLAND FIRE DEPARTMENT		PLANS & DETAILS
PHASE I: REPLACE CONTROL PANEL			DRAWN BY CRM		DWG. NO. 1 OF 6
PHASE II: INSTALL NEW DEVICES			CHECKED BY MLT		JOB NUMBER
PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE 1			CONTRACTOR LICENSE #		SCALE 3/32"=1'
				DATE 1/25/13	



FIRE ALARM SYSTEM LAYOUT – FIRST FLOOR




GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	<p>LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME</p> <p>CONTRACT WITH: WESTON ASSOCIATES MGMT.</p> <p>EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210</p>	FIRE ALARM SYSTEM
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72			OWNER PORTLAND FIRE DEPARTMENT		PLANS & DETAILS
PHASE I: REPLACE CONTROL PANEL			DRAWN BY CRM		DWG. NO. 2 OF 6
PHASE II: INSTALL NEW DEVICES			CHECKED BY MLT		JOB NUMBER
PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE 1			CONTRACTOR LICENSE #		SCALE 3/32"=1'
				DATE 1/25/13	




FIRE ALARM SYSTEM LAYOUT – SECOND FLOOR


SCALE: 1/8"=1'-0"

GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	<p>LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME CONTRACT WITH: WESTON ASSOCIATES MGMT.</p> <p>EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210</p>	FIRE ALARM SYSTEM
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72			OWNER PORTLAND FIRE DEPARTMENT		PLANS & DETAILS
PHASE I: REPLACE CONTROL PANEL			DRAWN BY: CRM		DWG. NO. 3 OF 6
PHASE II: INSTALL NEW DEVICES			CHECKED BY: MLT		JOB NUMBER
PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE I			CONTRACTOR LICENSE #	SCALE 3/32"=1'	DATE 1/25/13




FIRE ALARM SYSTEM LAYOUT – THIRD FLOOR

GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME CONTRACT WITH: WESTON ASSOCIATES MGMT. 	FIRE ALARM SYSTEM	
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72			OWNER PORTLAND FIRE DEPARTMENT		PLANS & DETAILS	DWG. NO. 4 OF 6
PHASE I: REPLACE CONTROL PANEL			DRAWN BY CRM		JOB NUMBER	SCALE 3/32"=1'
PHASE II: INSTALL NEW DEVICES			CHECKED BY MLT			DATE 1/25/13
PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE 1			CONTRACTOR LICENSE #			




FIRE ALARM SYSTEM LAYOUT - FOURTH FLOOR

GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME CONTRACT WITH: WESTON ASSOCIATES MGMT.	FIRE ALARM SYSTEM
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72 PHASE I: REPLACE CONTROL PANEL PHASE II: INSTALL NEW DEVICES PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE 1			OWNER PORTLAND FIRE DEPARTMENT DRAWN BY: CRM CHECKED BY: MLT CONTRACTOR LICENSE #		EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210





FIRE ALARM RISER DETAIL
SCALE: N.T.S.

GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME CONTRACT WITH: WESTON ASSOCIATES MGMT.	FIRE ALARM SYSTEM
-SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72 PHASE I: REPLACE CONTROL PANEL PHASE II: INSTALL NEW DEVICES PHASE II TO BE COMPLETED IMMEDIATELY AFTER PHASE I			OWNER PORTLAND FIRE DEPARTMENT DRAWN BY: CRM CHECKED BY: MLT CONTRACTOR LICENSE #		EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210




FIRE ALARM SYSTEM LAYOUT – GROUND FLOOR

SCALE: 1/8"=1'



FIRE ALARM SYSTEM LAYOUT – FIRST FLOOR



SCALE: 1/8"=1'



GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	FIRE ALARM SYST
SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72, 720.			OWNER	PLANS & DETAIL
PHASE 1: INSTALL NEW CONTROL PANEL			PORTLAND FIRE DEPARTMENT	DWG. NO.
PHASE 2: INSTALL NEW DEVICES			DRAWN BY CRM	1 OF 4
PHASE 2 TO BEGIN IMMEDIATELY FOLLOWING PHASE 1			CHECKED BY BWB	JOB NUMBER
			CONTRACTOR LICENSE #	SCALE AS SHOWN
				DATE 1/23/13



LONGFELLOW COMMONS
206 STATE ST.
PORTLAND, ME

EASTERN FIRE SERVICES, INC.
AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210



FIRE ALARM SYSTEM LAYOUT – SECOND FLOOR

SCALE: 1/8"=1'




FIRE ALARM SYSTEM LAYOUT – THIRD FLOOR

SCALE: 1/8"=1'


GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	FIRE ALARM SYST
SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72, 720.			OWNER	PLANS & DETAIL
PHASE 1: INSTALL NEW CONTROL PANEL			PORTLAND FIRE DEPARTMENT	DWG. NO. 2 OF 4
PHASE 2: INSTALL NEW DEVICES			DRAWN BY CRM	JOB NUMBER
PHASE 2 TO BEGIN IMMEDIATELY FOLLOWING PHASE 1			CHECKED BY BWB	SCALE AS SHOWN
			CONTRACTOR LICENSE #	DATE 1/23/13

LONGFELLOW COMMONS
206 STATE ST.
PORTLAND, ME

EASTERN FIRE SERVICES, INC.
AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210







FIRE ALARM SYSTEM LAYOUT - FOURTH FLOOR
SCALE: 1/8"=1'



GENERAL NOTES	DATE	REVISIONS	REQUIRED APPROVALS	FIRE ALARM SYST
SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72, 720.			OWNER	PLANS & DETAIL
PHASE 1: INSTALL NEW CONTROL PANEL			PORTLAND FIRE DEPARTMENT	DWG. NO. 3 OF 4
PHASE 2: INSTALL NEW DEVICES			DRAWN BY CRM	JOB NUMBER
PHASE 2 TO BEGIN IMMEDIATELY FOLLOWING PHASE 1			CHECKED BY BWB	SCALE AS SHOWN
			CONTRACTOR LICENSE #	DATE 1/23/13
<p style="text-align: center;">LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME</p> <p style="text-align: center;">EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210</p>				

SYMBOL LEGEND				
QUANT.	SYM.	DESCRIPTION	MODEL	BACK BOX
1		FIRE ALARM CONTROL PANEL	FS-250	ENCLOSURE
1		DIGITAL COMMUNICATOR	FS-DACT	FACP
61		CEILING SMOKE DETECTOR/BASE	HFP-11/DB-11	SINGLE GANG C OCTAGON BOX
4		THERMAL DETECTOR/ BASE	HFPT-11/DB-11	SINGLE GANG C OCTAGON BOX
134		135 FT/ROR HEAT DETECTOR/BASE	DT-135R	SINGLE GANG C OCTAGON BOX
21		MANUAL PULL STATION	MSM-KD/HTRI-M	3.5" DEEP SINGLE GANG
44		SINGLE INPUT MONITOR MODULE	HTRI-S	4" SQUARE BOX
1		DUAL INPUT MONITOR MODULE	HTRI-D	4" SQUARE BOX
5		SINGLE INPUT MONITOR MODULE W/ RELAY	HTRI-R	4" SQUARE BOX
3		FIRE ALARM MULTI CANDELLA STROBE	ZR-MC-R	4" SQUARE
41		FIRE ALARM MULTI CANDELLA HORN/STROBE	ZH-MC-R	4" SQUARE
44		FIRE ALARM HORN	ZH-R	4" SQUARE



GENERAL NOTES		DATE	REVISIONS	REQUIRED APPROVALS	LONGFELLOW COMMONS 206 STATE ST. PORTLAND, ME	FIRE ALARM SYST PLANS & DETAIL DWG. NO. 4 OF 4
SCOPE OF WORK: INSTALL NEW ADDRESSABLE FIRE ALARM SYSTEM. ALL INSTALLATION PRACTICES SHALL COMPLY WITH NFPA 70, 72, 720.				OWNER		
PHASE 1: INSTALL NEW CONTROL PANEL				PORTLAND FIRE DEPARTMENT		
PHASE 2: INSTALL NEW DEVICES				DRAWN BY CRM	CONTRACT WITH: WESTON ASSOCIATES MGMT	JOB NUMBER
PHASE 2 TO BEGIN IMMEDIATELY FOLLOWING PHASE 1				CHECKED BY BWB	EASTERN FIRE SERVICES, INC. AUBURN/LEWISTON INDUSTRIAL AIRPARK, AUBURN, MAINE 04210	SCALE AS SHOWN
				CONTRACTOR LICENSE #		DATE 1/23/13