

**SEQUENCE OF OPERATION MATRIX**

	<i>Alarm Signal to Central Station via Digital Communicator (DACT)</i> <i>Alarm Signal to Fire Department via Radio Master Box</i> <i>Activate Exterior Beacon</i> <i>Annunciate at Fire Alarm Control Panel</i> <i>Activate Horn Strobe Circuits</i> <i>Activate Elevator Recall Relay</i> <i>Record Event In Memory</i> <i>Supervisory Signal to Central Station via Digital Communicator (DACT)</i> <i>Trouble Signal to Central Station via Digital Communicator (DACT)</i>									
<b>System Inputs</b>	<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	<b>G</b>	<b>H</b>	<b>I</b>	<b>System Inputs</b>
Manual Pull Station	x	x	x	x	x		x			Manual Pull Station
Area Smoke Detector	x	x	x	x	x		x			Area Smoke Detector
Area Heat Detector	x	x	x	x	x		x			Area Heat Detector
Elevator Smoke Detector	x	x	x	x	x	x	x			Elevator Smoke Detector
Kitchen Hood System				x	x		x			Kitchen Hood System
Fire Alarm - AC Failure				x			x		x	Fire Alarm - AC Failure
Fire Alarm - Low Battery				x			x		x	Fire Alarm - Low Battery
Signal Line Open Circuit				x			x		x	Signal Line Open Circuit
Signal Line Ground Fault				x			x		x	Signal Line Ground Fault
Strobe Circuit Open				x			x		x	Strobe Circuit Open
Strobe Circuit Ground				x			x		x	Strobe Circuit Ground
System Ground Fault				x			x		x	System Ground Fault
	<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	<b>G</b>	<b>H</b>	<b>I</b>	