


DIA.	A	B	C	D	E	R
18"	9"	2'-3"	3'-10"	3'-0"	2 1/2"	11"
24"	9 1/2"	3'-7 1/2"	2'-6"	4'-0"	3"	14"
30"	12"	4'-6"	1'-7 1/4"	5'-0"	3 1/2"	15"
36"	15"	5'-3"	2'-10 1/4"	6'-0"	4"	1'-8"
42"	21"	5'-3"	2'-11"	6'-6"	4 1/2"	22"
48"	24"	6'-0"	2'-2"	7'-0"	5"	22"
54"	27"	5'-5"	2'-11"	7'-6"	5 1/2"	24"
60"	30"	5'-0"	3'-3"	8'-0"	6"	24"

NOTE:  
JOINTS MAY BE FURNISHED WITH EITHER BELL AND SPIGOT OR TONGUE AND GROOVE ENDS.


\* BAR RACKS ARE ONLY REQUIRED ON PIPES 18" AND OVER IN SIZE.

\* USE FIELD MITER FOR CULVERTS WITH A DIAMETER OF LESS THAN 18"


REQD FOR ALL INLETS/OUTLETS FOR PIPE OVER 18" DIAMETER.  
**A RCP FLARED END WITH BAR RACK DETAIL**  
N.T.S.



**B CONCRETE WASHOUT AREA**  
N.T.S.




**C TEMPORARY SLOPE DRAIN**  
N.T.S.



1. PREPARE SOIL BEFORE INSTALLING BLANKETS, INCLUDING ANY NECESSARY APPLICATION OF LIME, FERTILIZER, AND SEED. NOTE: WHEN USING CELL-O-SEED DO NOT SEED PREPARED AREA. CELL-O-SEED MUST BE INSTALLED WITH PAPER SIDE DOWN.
2. BEGIN AT THE TOP OF THE CHANNEL BY ANCHORING THE BLANKET IN A 6" (150MM) DEEP X 6" (150MM) WIDE TRENCH WITH APPROXIMATELY 12" (300MM) OF BLANKET EXTENDED BEYOND THE UP-SLOPE PORTION OF THE TRENCH. ANCHOR THE BLANKET WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" (300MM) APART IN THE BOTTOM OF THE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING. APPLY SEED TO COMPACTED SOIL AND FOLD REMAINING 12" (300MM) PORTION OF BLANKET BACK OVER SEED AND COMPACTED SOIL. SECURE BLANKET OVER COMPACTED SOIL WITH A ROW OF STAPLES/STAKES SPACED APPROXIMATELY 12" (300MM) ACROSS THE WIDTH OF THE BLANKET.
3. ROLL CENTER BLANKET IN DIRECTION OF WATER FLOW IN BOTTOM OF CHANNEL. BLANKETS WILL UNROLL WITH APPROPRIATE SIDE AGAINST THE SOIL SURFACE. ALL BLANKETS MUST BE SECURELY FASTENED TO SOIL SURFACE BY PLACING STAPLES/STAKES IN APPROPRIATE LOCATIONS AS SHOWN IN THE STAPLE PATTERN GUIDE. WHEN USING THE DOT SYSTEM, STAPLES/STAKES SHOULD BE PLACED THROUGH EACH OF THE COLORED DOTS CORRESPONDING TO THE APPROPRIATE STAPLE PATTERN.
4. PLACE CONSECUTIVE BLANKETS END OVER END (SHINGLE STYLE) WITH A 4" (100MM) OVERLAP. USE A DOUBLE ROW OF STAPLES STAGGERED 4" (100MM) APART AND 4" (100MM) ON CENTER TO SECURE BLANKETS.
5. FULL LENGTH EDGE OF BLANKETS AT TOP OF SIDE SLOPES MUST BE ANCHORED WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" (300MM) APART IN A 6" (150MM) DEEP X 6" (150MM) WIDE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING.
6. ADJACENT BLANKETS MUST BE OVERLAPPED APPROXIMATELY 2'-6" (50CM-12.5CM) (DEPENDS ON BLANKET SIZE) AND STAPLED.
7. IN HIGH FLOW CHANNEL APPLICATIONS, A STAPLE CHECK SLOT IS RECOMMENDED AT 30 TO 40' (9M-12M) INTERVALS. USE A DOUBLE ROW OF STAPLES STAGGERED 4" (100MM) APART AND 4" (100MM) ON CENTER OVER ENTIRE WIDTH OF THE CHANNEL.
8. THE TERMINAL END OF BLANKETS MUST BE ANCHORED WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" (300MM) APART IN A 6" (150MM) DEEP X 6" (150MM) WIDE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING.


NOTE:  
\* HORIZONTAL STAPLE SPACING SHOULD BE ALTERED IF NECESSARY TO ALLOW STAPLES TO SECURE THE CRITICAL POINTS ALONG THE CHANNEL SURFACE.  
\* IN LOOSE SOIL CONDITIONS, THE USE OF STAPLE OR STAKE LENGTHS GREATER THAN 6" (150MM) MAY BE NECESSARY TO PROPERLY ANCHOR THE BLANKETS.

**EROSION CONTROL BLANKET DETAIL FOR CHANNEL INSTALLATION**




1. PREPARE SOIL BEFORE INSTALLING BLANKETS, INCLUDING ANY NECESSARY APPLICATION OF LIME, FERTILIZER, AND SEED. NOTE: WHEN USING CELL-O-SEED DO NOT SEED PREPARED AREA. CELL-O-SEED MUST BE INSTALLED WITH PAPER SIDE DOWN.
2. BEGIN AT THE TOP OF THE SLOPE BY ANCHORING THE BLANKET IN A 6" (150MM) WIDE TRENCH WITH APPROXIMATELY 12" (300MM) OF BLANKET EXTENDED BEYOND THE UP-SLOPE PORTION OF THE TRENCH. ANCHOR THE BLANKET WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" (300MM) APART IN THE BOTTOM OF THE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING. APPLY SEED TO COMPACTED SOIL AND FOLD REMAINING 12" (300MM) PORTION OF THE BLANKET BACK OVER SEED AND COMPACTED SOIL. SECURE BLANKET OVER COMPACTED SOIL WITH A ROW OF STAPLES/STAKES SPACED APPROXIMATELY 12" (300MM) APART ACROSS THE WIDTH OF THE BLANKET.
3. ROLL THE BLANKETS (A) DOWN OR (B) HORIZONTALLY ACROSS THE SLOPE. BLANKETS WILL UNROLL WITH THE APPROPRIATE SIDE AGAINST THE SOIL SURFACE. ALL BLANKETS MUST BE SECURELY FASTENED TO SOIL SURFACE BY PLACING STAPLES/STAKES IN APPROPRIATE LOCATIONS AS SHOWN IN THE STAPLE PATTERN GUIDE. WHEN USING OPTIONAL DOT SYSTEM, STAPLES/STAKES SHOULD BE PLACED THROUGH EACH OF THE COLORED DOTS CORRESPONDING TO THE APPROPRIATE STAPLE PATTERN.
4. THE EDGES OF PARALLEL BLANKETS MUST BE STAPLED WITH APPROXIMATELY 2'-6" (50CM-12.5CM) OVERLAP DEPENDS ON BLANKET TYPE. TO ENSURE PROPER SEAM ALIGNMENT, PLACE THE EDGE OF THE OVERLAPPING BLANKET (BLANKET BEING INSTALLED ON TOP) EVEN WITH THE COLORED SEAM STITCH ON THE PREVIOUSLY INSTALLED BLANKET.
5. CONSECUTIVE BLANKETS SPICED DOWN THE SLOPE MUST BE PLACED END OVER END (SHINGLE STYLE) WITH AN APPROXIMATE 3" (75MM) OVERLAP. STAPLE THROUGH OVERLAPPED AREA, APPROXIMATELY 12" (300MM) APART ACROSS ENTIRE BLANKET WIDTH.


**D EROSION CONTROL BLANKET** NOTE: IN LOOSE SOIL CONDITIONS, THE USE OF STAPLE OR STAKE LENGTHS GREATER THAN 6" (150MM) MAY BE NECESSARY TO PROPERLY ANCHOR THE BLANKETS.  
N.T.S.




- NOTE:  
1. THE WOOD WASTE COMPOST/BARK MIX SHALL CONFORM TO THE FOLLOWING STANDARDS:  
A. MOISTURE CONTENT - 30-60%  
B. pH - 5.0-8.0  
C. SCREEN SIZE - 100% LESS THAN 3", MAX. 70% LESS THAN 1"  
D. NO LESS THAN 40% ORGANIC MATERIAL (DRY WEIGHT) BY LOSS OF IGNITION  
F. NO STONES LARGER THAN 2" IN DIAMETER
1. THE COMPOST BERM SHALL BE PLACED UNCOMPACTED, ALONG A RELATIVELY LEVEL CONTOUR.
  2. THE WOOD WASTE COMPOST/BARK FILTER BERM MAY BE USED IN LIEU OF SILTATION FENCE, AT THE TOE OF SHALLOW SLOPES, ON FROZEN GROUND, LEDGE OUT CROPS, VERY ROOTED FORESTED AREA OR AT THE EDGE OF GRAVEL PARKING AREAS.
  3. BERMS SHALL REMAIN IN PLACE UNTIL UPSTREAM AREA IS COMPLETED OR 70% CATCH OF VEGETATION IS ATTAINED. BERMS SHALL BE REMOVED BY SPREADING SUCH THAT THE NATIVE EARTH CAN BE SEEN BELOW.




**G WOOD WASTE COMPOST/BARK FILTER BERM DETAIL**  
N.T.S.




**H FLARED INLETS FOR 10" TO 18" PIPES**  
N.T.S.




**I STRAW WATTLE DETAILS**  
N.T.S.



**J RIPRAP CHANNEL DETAIL**  
N.T.S.



**K GEOTEXTILE PLACEMENT FOR PROTECTION OF SLOPES ADJACENT TO STREAMS AND TIDAL AREAS**  
N.T.S.



**L DIRTBAG AND SPECIFICATIONS FOR DEWATERING DETAIL**  
N.T.S.

	PROJECT	THE FOREFRONT AT THOMPSON'S POINT	<b>FAY, SPOFFORD &amp; THORNDIKE</b> ENGINEERS - PLANNERS - SCIENTISTS 778 MAIN ST, SUITE 8, SOUTH PORTLAND, ME 04106
	SHEET TITLE	EROSION AND SEDIMENT CONTROL DETAILS	
	CLIENT	FOREFRONT PARTNERS I, LP	
REV	DATE	DESCRIPTION	DRAWN: DED DESIGNED: BEK CHECKED: SRB FILE NAME: 2982.05-SUB DET SHEET
1	12.12.14	FINAL SUBDIVISION APPLICATION SUBMISSION	DATE: SEPT 2014 SCALE: N.T.S. JOB NO: 2982.05
REVISIONS			C-7.6

R:\2982.05 Amended Site Plan Part I\Cadd\Permit Set\Sub\DIVISION\2982.05-SUB DET.dwg dwg\_date: 12/15/2014 12:06 PM