



INSTALL 3 1/2" FIBERGLASS BATT INSULATION IN ALL EXTERIOR AND PARTY WALLS
 INSTALL 4 MIL POLYVAPOR BARRIER OVER INSIDE FACE OF STUDS-TAPE SEAMS AND AROUND ELECTRICAL AND OTHER PENETRATIONS

FILL COMPLETELY WITH FIBERGLASS BATT INSULATION THE SPACE BETWEEN THE CANTILEVERED AREA OVER THE FIRST FLOOR (FRONT AND REAR)

NOTE:
 PROVIDE ALTERNATE PRICE FOR DENSE PAK CELLULOSE INSULATION ALTERNATE INSULATION
 INSTALL DENSE PAK CELLULOSE INSULATION

CELLULOSE INSULATION SHALL BE GREEN FIBER NATURAL FIBER INSULATION OR EQUAL MEETING THE FOLLOWING REQUIREMENTS
 ASTM C159 - STANDARD SPECIFICATION FOR CELLULOSIC FIBER WOOD-BASED LOOSE-FILL THERMAL INSULATION
 MINIMUM OF 85% RECYCLED PAPER FIBERS

FINAL WALL INSULATION SHOULD BE A MINIMUM R-VALUE OF R-3.8 PER INCH WHEN INSTALLED AT 5.5 INCHES IN A 5.5 CAVITY STUD WALL.

INSTALL STABILIZED BORATE GRADE CELLULOSE INSULATION
 ONLY CELLULOSE INSULATION SHALL BE EQUIVALENT. CUT ONE PIECE OF NETTING FOR EACH WALL SECTION. STRETCH MATERIAL TIGHTLY WITHOUT WRINKLES AND SIDE STAPLE IN ON BOTH SIDES OF FRAMING AT EACH STUD BAY. STAPLES SHOULD BE NO MORE THAN 15 APART.

CELLULOSE INSULATION SHALL BE DENSE PAKED INTO CAVITIES AT 3.5 INCHES. CAVITIES SHALL BE SOLID WITH A WALL ROLLER TO SMOOTH OUT INSULATION PRIOR TO INSTALLING GYPSUM BOARD. FOLLOW ALL MANUFACTURER'S RECOMMENDED INSTALLATION INSTRUCTIONS AND RECOMMENDATIONS AND ALL STATE AND LOCAL CODES.

CEILING HEIGHT APPROX 8'-0"

2 BEDROOM UNIT - FIRST FLOOR

SCALE: 1/4"=1'-0"

RIVERTON DRIVE