


- NOTES:
- COORDINATE PLACEMENT OF SLAB WITH ALL UNDERSLAB UTILITIES. CONFIRM ALL DRAIN LOCATIONS WITH PLUMBING PLANS BEFORE BACKLASH PIPING.
 - SEE DET. 43/58 FOR TRENCH DRAIN INSTALLATION. REFER TO DRAWINGS 31-24, 31-25 & 31-26 FOR GENERAL NOTES, TYPICAL SECTIONS & CONCRETE DETAILS ETC.
 - DIMENSIONS & SCREEDS ARE FROM OUTSIDE TO OUTSIDE OF SCREEDS. SEE REFRIGERATION DRAWINGS FOR REFRIG. STUB-UP PIPING DETAIL.
 - PROVIDE COMPACTED STRUCTURAL FILL BELOW 4" CONCRETE SLAB & ABOVE CONTRACTOR PREPARED BUILDING PAD @ EL. 99'-0".
 - REFERENCE EL. 75.00 FT. = ELEV. 100'-0".
 - LOCATE CONSTRUCTION JOINTS AS SHOWN (3 HOUR CONDITION). DISCUSS WITH ARCHITECT & ENGINEER FOR CHANGING LOCATIONS.
 - PAINT 6" EDGE AND VERTICAL EDGE OF SIDEWALK YELLOW WHERE PAVEMENT IS NOT FLUSH WITH SIDEWALK.
- INDICATES 1/2" DEPRESSED SLAB
 - INDICATES 2" DEPRESSED SLAB



DATE	BY

DATE	BY

PROJECT TITLE
 Hannaford
 Riverside Street
 Portland, Maine

SHEET TITLE
 SLAB PLAN

DESIGN	L. WICHORSKI
DRAWN	J. MORIN
CHECKED	Digit
PROJECT MGR	BCM
DATE	AUGUST, 2004
©	2004 Hannaford Bros Co

SHEET
S7
 PROJ. NO. PRSSA