


**INSTALLATION:**

1. EXCAVATE A 6"x 6" TRENCH ALONG THE LINE OF PLACEMENT FOR THE FILTER BARRIER.
2. UNROLL A SECTION AT A TIME AND POSITION THE POSTS AGAINST THE BACK (DOWNSTREAM) WALL OF THE TRENCH.
3. DRIVE POSTS INTO THE GROUND UNTIL APPROXIMATELY 2" OF FABRIC IS LYING ON THE TRENCH BOTTOM. JOIN SECTION AS SHOWN ABOVE.
4. LAY THE TOE-IN FLAP OF FABRIC ONTO THE UNDISTURBED BOTTOM OF THE TRENCH, BACKFILL THE TRENCH AND TAMP THE SOIL. TOE-IN CAN ALSO BE ACCOMPLISHED BY LAYING THE FABRIC FLAP ON UNDISTURBED GROUND AND PILING AND TAMPING FILL AT THE BASE, BUT MUST BE ACCOMPANIED BY AN INTERCEPTION DITCH.
5. BARRIER SHALL BE MIRAFI SILT FENCE OR APPROVED EQUAL.

**FILTER BARRIER**  
NOT TO SCALE



**TYPICAL HOUSE LATERAL WYE CONNECTION DETAILS**  
NOT TO SCALE

**DETAIL SHEET**

FOR A PROPOSED NEW 1 1/2 STORY DWELLING  
DEDHAM STREET, PORTLAND, MAINE

FOR:  
**FOWLER-GREAVES CONSTRUCTION**

DRAWN BY:RTG

CHECKED BY:MMB

SCALE: 1"=40'

DATE OF SURVEY: 06-10-2008

JOB NUMBER:  
2008004

SHEET: 3 of 3.

PREPARED BY:

**OCEAN PARK LAND SURVEYING LLC**

P.O. BOX 7265

OCEAN PARK, MAINE 04063

207-749-9471 OCEANPARKLLC@GWI.NET

DRAWER:2008 NO:17