REMOTE TELLER TUBES AND CANOPY STRUCTURE DURING CONSTRUCTION. REMOVE EXISTING MECHANICAL UNIT & ASSOCIATED WIRING SALVAGE FOR

DEMOLISH PORTION OF CANOPY WALL & STRUCTURE. SEE SECTIONS AND

DEMOLISH PORTION OF EXTERIOR SOFFIT FRAMING & LIGHTING. SAVE EXST.

DEMOLISH PORTION OF ROOF. SEE SECTIONS AND DETAILS FOR MORE

DEMOLISH EXHAUST FAN IN SOFFIT WALL. PATCH HOLE WITH MATERIAL TO

DEMOLISH EXST. ROOFING SYSTEM. PRESERVE ROOF STRUCTURE AND PREP

DETAILS FOR ADDITIONAL DEMOLITION INFORMATION.

EXISTING CEILING AND LIGHT FIXTURES TO REMAIN.

REMOVE EXISTING CO-AXIAL CABLING IN WALL/CEILING.

WIRING FOR USE WITH NEW LIGHTING.

DEMOLISH CANOPY.

DEMOLISH PARAPET CAP.

DEMOLITION INFORMATION.

MATCH EXISTING ADJACENT.

FOR NEW ROOFING SYSTEM.

345

CUMBERL

JOB NO.

12044 DRWN. JKP/ER CHECK Checker


SCALE:


1/4" = 1'-0" ISSUE

30 August, 2013

DEMOLITION PLAN

SHEET





A3 FIRST FLOOR DEMO PLAN
1/4" = 1'-0"

FOR ACCESS DURING PHASE 1. RE-INSTALL

STOREFRONT WHEN PHASE 1 IS COMPLETE.

L----J

EXST. CANOPY

ABOVE TO BE MODIFIED -

TRUE NORTH

NORTH

DASHED LINES INDICATE ITEMS TO BE REMOVED.

REMAIN - PATCH &

REPAIR AS NECESSARY