

Triple 1-3/4" x 11-7/8" VERSA-LAM® 2.0 3100 SP

Floor Beam\FB02

Dry | 1 span | No cantilevers | 0/12 slope

Tuesday, July 15, 2014

BC CALC® Design Report - US

Build 2627

Job Name: Francoeur Construction


Address:

250 Burnside Ave City, State, Zip: Portland, ME

Rufus Deering Customer: Code reports: ESR-1040

File Name: BC CALC Project Description: Designs\FB02

Specifier: Designer: Company: Misc:



Total of Horizontal Design Spans = 12-00-00

Reaction Summary (Down / Uplift) (lbs)									
Bearing	Live	Dead	Snow	Wind	Roof Live				
B0	1,680 / 0	1,329 / 0	1,146 / 0						
B1	1,680 / 0	3,178 / 0	6,707 / 0						

						Live	Dead	Snow	Wind	Roof Live	Trib.
	ad Summary Description	Load Type	Ref	f. Start	End	100%	90%	115%	160%	125%	
1	Standard Load	Unf. Area (lb/ft^2)	L	00-00-00	12-00-00	20	10				14-00-00
2	Reaction from Desi	Conc. Pt. (lbs)	L	10-03-00	10-03-00		2,610	7,853			n/a

Controls Summary	Value	% Allowable	e Duration	Case	Location
Pos. Moment	17,062 ft-lbs	46.5%	115%	2	10-03-00
End Shear	9,717 lbs	71.3%	115%	2	01-00-12
Total Load Defl.	L/528 (0.273")	45.4%	n/a	3	06-05-12
Live Load Defl.	L/825 (0.175")	43.7%	n/a	6	06-06-03
Max Defl.	0.273"	27.3%	n/a	3	06-05-12
Span / Depth	12.1	n/a	n/a	0	00-00-00

Notes

Design meets Code minimum (L/240) Total load deflection criteria.

Design meets Code minimum (L/360) Live load deflection criteria. Design meets arbitrary (1") Maximum total load deflection criteria.

Minimum bearing length for B0 is 1-1/2".

Minimum bearing length for B1 is 2-1/2".

Entered/Displayed Horizontal Span Length(s) = Clear Span + 1/2 min. end bearing +

1/2 intermediate bearing

Calculations assume Member is Fully Braced.

Design based on Dry Service Condition.

Deflections less than 1/8" were ignored in the results.

Fastener Manufacturer: TrussLok (tm)

Disclosure

Completeness and accuracy of input must be verified by anyone who would rely on output as evidence of suitability for particular application. Output here based on building code-accepted design properties and analysis methods. Installation of BOISE engineered wood products must be in accordance with current Installation Guide and applicable building codes. To obtain Installation Guide or ask questions, please call (800)232-0788 before installation.\n\nBC CALC®, BC FRAMER®, AJS™ ALLJOIST®, BC RIM BOARD™, BCI®, BOISE GLULAMTM, SIMPLE FRAMING SYSTEM®, VERSA-LAM®, VERSA-RIM PLUS®, VERSA-RIM®, VERSA-STRAND®, VERSA-STUD® are trademarks of Boise Cascade Wood Products L.L.C.