REQUIREMENTS.

FOURTH FLOOR - LIGHTING

SCALE: 1/16" = 1'-0"

GENERAL NOTES:

SEE ELECTRICAL E5.X SHEETS FOR TYPICAL ELECTRICAL IN RESIDENTIAL SUITES. BASEBOARD AND WALL HEATERS TO BE WHITE.

CONNECT SUITES TO PANELS AS INDICATED ON POWER PLANS.

CONSULT FINISH SCHEDULE FOR CEILING TYPE IN COMMON AREAS. COORDINATE FIXTURE TYPE AND MOUNTING WITH CEILING TYPE. SEE LIGHT FIXTURE PROTECTION DETAIL ON 6/E2.2b AND TYPICAL FOR RECESSED LIGHT FIXTURES AND EXHAUST FANS IN FIRE RATED CEILINGS. MODIFY DETAIL AS NEEDED TO

MATCH UNIT INSTALLED. PENETRATIONS OF FIRE RATED CONSTRUCTION OR DRAFT STOP CONSTRUCTION TO BE

INSTALLED AND PROTECTED AS REQUIRED BY LOCAL CODES AND BUILDING AUTHORITY. SEE ARCH. FOR REQUIREMENTS ELECTRICAL CONTRACTOR RESPONSIBLE FOR DETERMINING NUMBER AND SIZE OF

CONDUCTORS, GROUND, AND NEUTRAL WIRES. SEE PANEL SCHEDULES FOR MIN. SIZES. COORDINATE MECHANICAL EQUIPMENT ELECTRICAL CONNECTIONS WITH MECHANICAL DRAWINGS AND EQUIPMENT FURNISHED. VERIFY LOCATIONS, CHARACTERISTICS AND LOADS, AND ADJUST WIRE AND BREAKER SIZES AS NEEDED. CONNECT PERIPHERALS AND INTERLOCK WITH OTHER MECHANICAL EQUIPMENT AS SHOWN ON MECHANICAL DRAWINGS

PROVIDE DUCT SMOKE (PHOTO TYPE) DETECTORS AT RETURN OF AIR HANDLING EQUIPMENT IF REQUIRED BY LOCAL CODE CONNECT DUCT SMOKE DETECTORS TO SHUT DOWN AIR HANDLING UNIT AND PROVIDE

DETECTOR OUTPUT TO FIRE ALARM PANEL. CONNECT CORRIDOR NON-EMERGENCY LIGHTING THROUGH AUTOMATIC LIGHTING

REMOTE RESET LIGHT/ALARM IN CORRIDOR WALL CLOSEST TO UNIT. CONNECT SMOKE

CONTROLLER LOCATED IN MECHANICAL ROOM. PROVIDE LINK SEAL LINK SLEEVE AT BUILDING ELECTRICAL PENETRATIONS IN FOUNDATION OR WHERE EXPOSED TO EARTH/ELEMENTS.

PROVIDE WARNING SIGN AT DISCONNECTS THAT SERVE EQUIPMENT LOCATIONS WITH MORE THAN ONE DISCONNECT. EQUIPMENT WITH MORE THAN ONE DISCONNECT SHALL HAVE LOCKABLE DISCONNECTS.

DO NOT USE HAMMERS OR BLUNT FORCE DEVICES TO "KNOCK-OUT" WIREWAYS IN BUILDING MATERIALS MAINTAIN NOT LESS THAN 18" FROM EDGE OF JOISTS. SEE DETAIL #11/E2.2b AND #14/E2.2b FOR ALLOWABLE BORING/NOTCHING OF MEMBERS. SEE ARCH FOR REQUIREMENTS. CIRCUIT "E" DESIGNATED LIGHT AND RECEPTACLES FIXTURES TO EMERGENCY PANEL.

ELECTRICAL KEY NOTES:

CONNECT 120 VOLT SINGLE PHASE WASHING MACHINE. PROVIDE ONE CIRCUIT FOR

1 EACH MACHINE. (MOUNT 40" A.F.F.) CONNECT 120 VOLT SINGLE PHASE GAS CLOTHES DRYER. PROVIDE ONE CIRCUIT FOR (2)EACH MACHINE. RUN 3/4" EMT FROM 1ST FLOOR. LAUNDRY ROOM TO ATTIC FOR FUTURE

DRYER BOOSTER FAN. (MOUNT 40" A.F.F.)

3 ELECTRIC RANGE. PROVIDE NEMA 14-50R 50 AMP 120/208 VOLT SINGLE PHASE RANGE RECEPTACLE AT 6" A.F.F.

ENTRY CANOPY / EXIT LIGHTS. CONNECT TO EXTERIOR LIGHTING CONTROL SEE DETAIL. 3/E2.2b (5) NOT USED

PROVIDE TYPE "V" FIXTURE AND GFI RECEPTACLE IN ELEVATOR PIT. DO NOT CONNECT ON SAME CIRCUIT. MOUNT SWITCH IN PIT. MOUNT FIXTURES TO AVOID CAR.

PROVIDE 20AMP ELEVATOR CAB LIGHT FUSED DISCONNECT IN EQUIPMENT ROOM CIRCUITED TO EMERGENCY PANEL. FUSE SIZE PER MANUFACTURER. TO EXTERIOR PARKING AREA. PATHWAY AND LANDSCAPE LIGHTING. CIRCUIT TO PANEL VIA EXTERIOR LIGHTING CONTROL SEE SITE PLAN DRAWING(S) FOR LOCATIONS AND

9 ELECTRICAL MAIN DISTRIBUTION PANEL. SEE ONE-LINE.

\ DOMESTIC COLD WATER AND FIRE SPRINKLER SERVICE ENTRANCES FOR GROUNDING. COORDINATE WITH PLUMBING CONTRACTOR.

EMERGENCY STANDBY ENGINE GENERATOR, SEE SPECIFICATIONS, SEE SITE (E1.0/A1.1) / PLAN FOR LOCATION

AUTOMATIC TRANSFER SWITCH FURNISHED AS PART OF ENGINE GENERATOR PACKAGE.

SEE SPECIFICATIONS AND ONE-LINE. \ PROVIDE FUSED DISCONNECT ELEVATOR MODULE WITH INTEGRAL SHUNT-TRIP FOR

13/ ELEVATOR MACHINE. COORDINATE FUSE REQUIREMENTS WITH ELEVATOR MANUFACTURER. CONNECT TO FIRE ALARM AND REMOTE SHUNT-TRIP SWITCH. COOPER BUSMAN, EATON ELEVATOR CONTROL SWITCH ES SERIES, OR APPROVED. TELEPHONE TERMINAL BOARD. SEE TELEPHONE SECTION OF SPECIFICATIONS. PROVIDE

⁴/ DOUBLE DUPLEX RECEPTACLE MOUNTED ON BACKBOARD AND TWO DEDICATED CIRCUITS AND #6 EQUIPMENT GROUND CONNECTED TO GROUND BUS AT MDP. TELEVISION TERMINAL BD. SEE TELEVISION SECTION OF SPECIFICATIONS. PROVIDE DOUBLE DUPLEX RECEPTACLE MOUNTED ON BACKBOARD AND TWO DEDICATED

CIRCUITS AND #6 EQUIPMENT GROUND CONNECTED TO GROUND BUS AT MDP. IRRIGATION CONTROL PANEL. PROVIDE RECEPTACLE ON DEDICATED CIRCUIT. STUB OUT A 2" PVC CONDUIT TO EXTERIOR OF BUILDING. COORDINATE LOCATION AND REQUIREMENTS WITH IRRIGATION CONTRACTOR.

POWER DOOR CONNECTED TO ATRIUM SMOKE CONTROL SYSTEM. SEE DETAIL 15/E2.2b AND SEQUENCE OF OPERATION ON E1.6PSEE SPECIFICATION SECTION 16100 FOR ADDITIONAL WIRING REQUIREMENTS.

18 INSTALL RECEPTACLE HORIZONTALLY.

LOCATE FIXTURES IN ATTIC SPACE FOR EACH WING. MOUNT IN AREAS TO PROVIDE LIGHT FOR MAINTENANCE USE. PROVIDE PILOT LIGHT SWITCH AT EACH ACCESS INSIDE OF

PROVIDE WEATHERPROOF LIGHT FIXTURE AND WEATHERPROOF GFI RECEPTACLE WITHIN 10 FEET OF MECHANICAL EQUIPMENT. COORDINATE LOCATION WITH MECHANICAL.

KITCHEN MAKE-UP AIR UNIT. ROUTE FAN POWER CONDUCTORS THROUGH SUPPLY VFD#1 LOCATED IN ENERGY MANAGEMENT SYSTEM (EMS) CONTROL PANEL LOCATED ON THE SIDE OF THE KITCHEN HOOD. PROVIDE ONE 3/4" CONDUIT FOR CONTROL WIRING FROM EMS CONTROL PANEL TO MAKE-UP AIR UNIT. PROVIDE TWO SETS OF 2-WIRE 16 AWG SHIELDED MULTI-CONDUCTOR CABLES BETWEEN MAU AND EMS PANEL. DO NOT ROUTE CONTROL CABLE ADJACENT TO HIGH POWER WIRING. COORDINATE WITH KITCHEN HOOD VENTILATION CONTROL CONSULTANT DRAWINGS H-3 AND H-4. ACTIVATION OF ANSUL SYSTEM SHALL SHUT DOWN MAU. FUSE SIZE PER MANUFACTURER.

THRU-WALL HVAC UNIT, SEE MECHANICAL SPECIFICATION. FURNISHED BY OWNER. INSTALLED BY MECHANICAL CONTRACTOR.

GAS FIRED WATER HEATERS. CIRCUIT ELECTRICAL GAS WATER HEATER CONNECTIONS TO BACK-UP POWER PANEL. HOT WATER RECIRCULATING PUMPS. FRACTIONAL HORSEPOWER 120V SINGLE PHASE. CIRCUIT TO BACK-UP POWER PANEL.

AC-1 PACKAGED ROOFTOP GAS PACK AIR CONDITIONING EQUIPMENT. SEE MECHANICAL EQUIPMENT SCHEDULE. SEE DETAIL 17/E2.2b.

KITCHEN RANGE HOOD EXHAUST FAN. ROUTE FAN POWER CONDUCTORS THROUGH EXHAUST VFD#2 LOCATED IN ENERGY MANAGEMENT SYSTEM (EMS) CONTROL PANEL LOCATED ON THE SIDE OF THE KITCHEN HOOD. COORDINATE WITH KITCHEN HOOD VENTILATION CONTROL CONSULTANT DRAWINGS H-2 AND H-4. FUSE SIZE PER MANUFACTURER.

EF-6/6a. CONNECT TO EMERGENCY PANEL SEE DETAILS ON M4.2. FUSE PER MANUFACTURER AND NEC. SEE SPECIFICATIONS FOR ADDITIONAL REQUIREMENTS SPECIFIC TO THIS EQUIPMENT. SEE DETAIL 15/E2.2b.

AC-2 PACKAGED ROOFTOP GASPACK AIR CONDITIONING EQUIPMENT. SEE MECHANICAL EQUIPMENT SCHEDULE. FUSE PER MANUFACTURER. SEE DETAIL 17/E2.2b. (30) COORDINATE LIGHTING WITH EQUIPMENT. CHAIN OR SURFACE MOUNT.

 $raket{31}$ MOUNT LIGHTS, RECEP., SWITCHES AND TIMERS ON WALL NEXT TO CATWALK.

 λ SF-2 SUPPLY FAN FOR COOLING AND HEATING CORRIDORS. SEE MECHANICAL EQUIPMENT SCHEDULE FOR DESCRIPTION. SEE DETAIL 17/E2.2b.

 $\langle 33
angle$ 1/12 HP ATTIC FAN ON ROOF. PROVIDE INDIVIDUAL DISCONNECTS. MOUNT FAN CONTROL 12" BELOW ROOF SHEATHING ON WALL NEXT TO CATWALK. SEE DETAIL 8/E2.2b

QMARK MUH-03-81 RATED 3KW AT 208 VOLT 1 PHASE: SUSPENDED FROM CEILING, CONTROLLED BY REMOTE WALL THERMOSTAT.

 $\langle 35 \rangle$ 30 AMP 2 POLE CIRCUIT FOR COMBO WASHER & DRYER UNIT. PROVIDE POWER FOR GAS FIRE PLACE PER MANUFACTURER REQUIREMENTS. PROVIDE SWITCH FOR FAN AND IGNITOR.

(37) LOCATION OF FUTURE DOOR (DO NOT CIRCUIT (WIRE) IN THIS LOCATION.

(38) NOT USED

30 AREA OF RESCUE ASSISTANCE ANNUNCIATOR. CORNELL 4200 SERIES. WIRE PER MANUFACTURER REQUIREMENTS, NOT LESS THAN #12 AUG. COPPER FOR POWER. PROVIDE BATTERY BACKUP BY MANUFACTURER AND LOCATE ABOVE CEILING IN OFFICE151. SEE 1/E5.1. LABEL ANNUNCIATOR PER AHJ REQUIREMENTS. SYSTEM PROVIDED BY OWNER.

AREA OF RESCUE CALL STATION. CORNELL 4200 SERIES. CONNECT TO ANNUCIATOR PANEL, IN FOYER, PER MANUFACTURER REQUIREMENTS. SYSTEM PROVIDED BY OWNER. \setminus EMERGENCY CALL REMOTE HEAD END. VERIFY LOCATION AND ELECTRICAL

(41) REQUIREMENTS WITH GENERAL CONTRACTOR. SHUTDOWN KITCHEN EQUIPMENT AND RECEPTACLE POWER UNDER HOOD UPON ACTIVATION OF ANSUL SYSTEM. SEE KITCHEN DRAWINGS.

GFI RECEPTACLE @ +48 FOR WATER SOFTENER, CONNECT TO DEDICATED 120V CIRCUIT. OWNER SUPPLIED WATER SOFTENER. CONTRACTOR TO INSTALL. 44) FRACTIONAL HP FAN MOTOR, 120V. CONNECT TO SWITCHED LEG OF LIGHTING CIRCUIT

45) PROVIDE GFI BREAKER. \langle 46angleKITCHEN WALK-IN FREEZER & COOLER CONDENSING UNITS. REFER TO KITCHEN PLANS.

FIRE/SMOKE DAMPER CONNECTION. CIRCUIT TO BACK-UP POWER PANEL. SEE DETAIL 12/E2.2b. DO NOT CONNECT MORE THEN SEVEN FSD'S TO EACH CIRCUIT. EMERGENCY CALL SYSTEM BACK BOARD. PROVIDE RECEPTACLE ON DEDICATED CIRCUIT.

49 NOT USED \hat{N} BROAN MODEL 154 LOW PROFILE CEILING HEATER. 120 VOLT, 1,250 WATTS. WITH MODEL

86W LINE-VOLTAGE THERMOSTAT. $\langle 51 \rangle$ PROVIDE UN-SWITCHED/UNCONTROLLED HOT TO EXIT SIGNS, TYPICAL.

 $\langle 52 \rangle$ WIRE ATTIC LIGHTS TO EMERGENCY CIRCUIT. \nearrow PROVIDE #6 CU GROUND WIRE FOR P.A. SYSTEM TO BUILDING GROUND IN MECHANICAL.

 $\langle 54 \rangle$ ELECTRIC DRYER-VERIFY ELEC. REQUIREMENTS.

WIRE FOR FUTURE THRU-WALL PTAC UNIT TO REPLACE BASEBOARD IN "C" UNIT DEDROOMS, SEE DETAIL "C-UNIT, TYPICAL." ON E5.X SERIES. DO NOT CIRCUIT (WIRE) IN

 \langle 56angle PROVIDE EMERGENCY POWER SWITCH/DIMMER BYPASS RELAY. SEE DETAIL 5/E2.2b.

 \langle 57anglePROVIDE SEPARATE BOX FOR EMERGENCY CIRCUIT.


(58) CONNECT VIA LIGHTING CONTROLLER. SEE DETAIL 3/E2.2b.

SINGLE POINT POWER CONNECTION. PROVIDE CONNECTION TO EXTERIOR CONDENSING UNIT. SEE MECHANICAL.

PROVIDE CONDUCTORS FOR BASEBOARD CONNECTIONS. INCLUDE REMOTE THERMOSTAT WIRING.

ONLY HEAT AND FAN TO OPERATE WHEN EMERGENCY POWER IS IN OPERATION. PROVIDE DUAL CONNECTION TO UNIT. MECHANICAL UNIT MODIFICATIONS IS NOT ACCEPTABLE. SEE MECHANICAL.

 $\langle 62 \rangle$ PROVIDE CF-1 CEILING FAN WITH SEPARATE SWITCH FOR FAN AND LIGHT. SEE E5



ITEM: RECESSED FLUORESCENT LIGHT FIXTURE DISCONNECT SWITCH THERMOSTATS FUSED DISCONNECT SWITCH DOOR HOLDERS 75" TO CENTER SURFACE MOUNT FLUORESCENT LIGHT FIXTURE TRANSFORMER **EMERGENCY CALL** OPEN CHANNEL FLUORECENT, TYPE INDICATED PNL W1A ELECTRICAL PANEL OR ENCLOSURE, DESIGNATION NOTED SPEAKERS & PULL STATIONS WALL MOUNT FIXTURE, TYPE INDICATED WALL LIGHTS IN CORRIDORS 80" TO CENTER LINE ELECTRICAL MOTOR LOAD SURFACE MOUNT OR CHAIN HUNG FIXTURE, TYPE INDICATED EXTERIOR WALL LIGHTS 96" TO CENTER LINE (U.N.O.) — C— CONTROL CABLE RECESSED FIXTURE, TYPE INDICATED **OUTLETS (COMMON AREAS)** SPECIAL RECEPTACLE AREA OF RESCUE SIGN - SEE LIGHTING SCHEDULE OUTLETS (SUITE AREAS) EXIT LIGHT, DIRECTIONAL ARROWS AS INDICATED. ▼ TV TELEVISION SIGNAL CONNECTION LIGHT SWITCH WIRE ALL EXIT LIGHTS TO NEAREST EM. LIGHT CIRCUIT. TELEPHONE CONNECTION S.P.S.T. SWITCH, DIMMER SWITCH, FAN SPEED COUNTER OUTLETS 44" TO BOTTOM CONTROL SWITCH EMERGENCY PULL SWITCH 2" TO BOTTOM, ABOVE TREAD STAIR LIGHTS $\$_3\$_{\mathbb{R}}$ 3-WAY SWITCH, PILOT LIGHT SWITCH, KEYED SWITCH THERMOSTAT ELECTRICAL PANEL 80" TO TOP OF PANEL TIMESWITCH AUTOMATIC WALL SWITCH BATHROOM WALL VANITY LIGHT 6'-11" TO CENTER (SEE NOTE #1) TRANSFORMER DUPLEX RECEPTACLE, SPLIT WIRED WITH 1/2 SWITCHED, ABOVE 000CEILING MOUNTED OCCUPANCY SENSOR DOUBLE DUPLEX (TWO) DUPLEX RECEPTACLE JUNCTION BOX "E" INDICATES WIRING TO EMERGENCY POWER. SEE SCHEDULE ON FLOOR BOX RECEPTACLE . CENTER OVER CABINET BASE PROVIDE BACKING IF REQUIRED. 208V, 1P RECEPTACLE - 20A EXCEPT WHEN NOTED WEATHER PROOF . INFORMATION SHOWN FOR REFERENCE, CONFORM TO ARCH, ADA, AND CODE GROUND FAULT CURRENT INTERRUPTING RECEPTACLE

THROUGH WALL PTAC UNIT. SEE MECHANICAL.

CONVENIENCE OUTLET



DENCI POF

8/28/2015

REVISED DATE

SHEET